Projector **CP-X417** User's Manual (detailed) Operating Guide



Thank you for purchasing this projector.

▲ **WARNING** ► Before using this product, please read all manuals for this product. Be sure to read "Safety Guide" first. After reading them, store them in a safe place for future reference.

About this manual

Various symbols are used in this manual. The meanings of these symbols are described below.

- ▲ **WARNING** This symbol indicates information that, if ignored, could possibly result in personal injury or even death due to incorrect handling.
- ▲ **CAUTION** This symbol indicates information that, if ignored, could possibly result in personal injury or physical damage due to incorrect handling.
 - Please refer to the pages written following this symbol.

NOTE • The information in this manual is subject to change without notice. • The manufacturer assumes no responsibility for any errors that may appear in this manual.

• The reproduction, transfer or copy of all or any part of this document is not permitted without express written consent.

Trademark acknowledgment

- Mac is registered trademarks of Apple Computer, Inc.
- VESA and SVGA are trademarks of the Video Electronics Standard Association.
- Windows is a registered trademark of Microsoft Corporation.
- HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

All other trademarks are the properties of their respective owners.

Contents

About this manual1	PICTURE menu
Contents	Brightness, Contrast, Gamma,
Projector features3	COLOR TEMP, COLOR, TINT, SHARPNESS,
Preparations	My memory
Contents of package	IMAGE menu
Fastening the lens cover	ASPECT, OVER SCAN, V POSITION,
Part names	H POSITION, H PHASE, H SIZE,
	AUTO ADJUST EXECUTE
Projector	INPUT menu
Control panel	PROGRESSIVE, VIDEO NR, COLOR SPACE,
Rear panel 5 Remote control 6	Component, Video format, Hdmi,
	FRAME LOCK, COMPUTER IN, RESOLUTION
Setting up7	SETUP menu
Arrangement	Auto keystone 🖾 Execute, Keystone 🖾,
Connecting your devices	Keystone 🖾, Whisper, Mirror, Volume,
Using a USB storage	Speaker, Audio, Hdmi audio
Using an SD card	SCREEN menu
Connecting power supply 13	LANGUAGE, MENU POSITION, BLANK,
Using the security bar and slot 13	START UP, MyScreen, MyScreen Lock,
Remote control14	Message, Source name
Putting batteries 14	OPTION menu
About the remote control signal 14	AUTO SEARCH, AUTO KEYSTONE 🖾,
Changing the frequency of remote control signal 15	AUTO ON, AUTO OFF, LAMP TIME, FILTER TIME,
Using as a simple PC mouse & keyboard 15	My BUTTON, SERVICE, SECURITY
Power on/off16	MIU menu53
Turning on the power	LIVE MODE, LIVE MODE SETTING,
Turning off the power	PC-LESS PRESENTATION, SETUP,
Operating 17	PROJECTOR NAME, e -shot, Information,
Adjusting the volume	Service
Temporarily muting the sound 17	C.C. (closed caption) menu63
Selecting an input signal 17	Display, Mode, Channel
Searching an input signal 18	Maintenance 64
Selecting an aspect ratio	Replacing the lamp 64
Adjusting the projector's elevator 19	Cleaning and replacing the air filter 66
Adjusting the zoom and focus 19	Replacing the internal clock battery 68
Using the automatic adjustment feature 20	Other care
Adjusting the position 20	Troubleshooting70
Correcting the keystone distortions 21	Related messages
Using the magnify feature 21	Regarding the indicator lamps 71
Freezing the screen	Shutting the projector down 72
Temporarily blanking the screen 22	Resetting all settings72
Using the menu function	Phenomena that may be easy
EASY MENU	to be mistaken for machine defects 73
Aspect, Auto keystone 🖾 Execute,	Specifications
Keystone 🖾, Keystone 🖾, Picture mode,	
BRIGHTNESS, CONTRAST, COLOR, TINT,	
SHARPNESS, WHISPER, MIRROR, RESET,	
FILTER TIME, LANGUAGE, Go to Advanced Menu	

Projector features

This product realizes the large projection image of various image signals, even if in a small space. This product also can offer you convenience and various uses by the following features.

- ✓ It is possible to project the images from an SD memory card or USB memory by the PC-LESS Presentation function of this projector.
- ✓ This projector can be controlled and monitored via LAN connection.
- ✓ Using the designated wireless network card (optional) realizes wireless I AN connection

Preparations

Contents of package


Please see the "Contents of package" section in the User's Manual (concise) which is a book. Your projector should come with the items shown there. Contact immediately your dealer if anything is missing.

NOTE • Keep the original packing materials, for future reshipment. Be sure to use the original packing materials when moving the projector. Use special caution for the lens.

Fastening the lens cover

To avoid losing the lens cover, please fasten the lens cover to the projector using the enclosed strap.


- Fix the strap to the strap hole of the lens cover.
- 1. Thread one end of the strap through the strap hole of the lens cover and make the loop at the end, and let the other end of the strap through the loop. Not have a knot in the strap at either end.



- 2. Fix the strap to the strap hole of the projector. Thread the other end of the strap through the strap hole of the projector and make the loop there. Let the lens cover with the one end of strap though the loop.







▲ **WARNING** ► HOT! : Do not touch around the lamp cover and the exhaust vents during use or just after use, since it is too hot.

► Do not look into the lens or vents while the lamp is on, since the strong light is not good for your eyes.


► Do not handle the elevator buttons without holding the projector, since the projector may drop down.

▲ **CAUTION** ► Maintain normal ventilation to prevent the projector from heating up. Do not cover, block or plug up the vents. Do not place anything that can stick or be sucked to the vents, around the intake vents. Clean the air filter periodically.

► Do not use the security bar and slot to prevent the projector from falling down, since it is not designed for it.

Control panel


- (1) STANDBY/ON button (**L16**)
- (2) INPUT button (117, 23)
- (3) MENU button (**23**) It consists of four cursor buttons.
- (4) POWER indicator (**116, 71**)
- (5) TEMP indicator (171)
- (6) LAMP indicator (171)



Rear panel

- (1) AUDIO IN1 port (**19**) (2) AUDIO IN2 port (**19**)
- (3) AUDIO OUT port ($\square 9$)
- (4) COMPUTER IN1 port (
- (5) COMPUTER IN2 port (
- (6) MONITOR OUT port (
- (7) Shutdown switch ($\square 72$)
- (8) CONTROL port ($\square 9$)
- (0) USB port ($\square 0$)
- (9) USB port (

- (10) COMPONENT (Y, Cb/Pb, Cr/Pr) ports (19) (11) VIDEO port (19) (12) S-VIDEO port (19)
- (13) AUDIO IN3 (L,R) ports (
- (14) LAN port (
- (15) USB STORAGE port (
- (16) SD card slot (**19**)
- (17) HDMI port (




 \triangle **CAUTION** \triangleright Use the shutdown switch only when the projector is not turned off by normal procedure, since pushing this switch stops operation of the projector without cooling it down.




Remote control

(1) VIDEO button (**1**) (2) COMPUTER button (**117**) (3) SEARCH button (118) (4) STANDBY/ON button (116) (5) ASPECT button (118) (6) AUTO button (**120**) (7) BLANK button (**122**) (8) MAGNIFY - ON button (121) (9) MAGNIFY - OFF button (**115, 21**) (10) HOME button (**11**) (11) END button (**11**) (12) PAGE UP button (115) (13) PAGE DOWN button (115) (14) VOLUME button ((15) MUTE button (**15**, **17**) (16) FREEZE button ((17) MY BUTTON - 1 button (44) (18) MY BUTTON - 2 button (44) (19) KEYSTONE button (221) (20) POSITION button (**120, 23**) (21) MENU button (**123**) (22) ▲/▼/◀/► cursor buttons (□15, 23, 24) (23) ENTER button (115, 23, 24) (24) ESC button (115, 23) (25) RESET button (115, 23, 24)

(26) Battery cover (**111**)



Back of the remote control



Setting up

Install the projector according to the environment and manner the projector will be used in.


Arrangement

Refer to the illustrations and tables below to determine screen size and projection distance.


The values shown in the table are calculated for a full size screen: 1024×768


- (a) Screen size (diagonal)
- (b) Projection distance (±10%)
- C), C2 Screen height (±10%)

On a horizontal surface



Suspended from the ceiling





Keep a space of 30 cm or more between the sides of the projector and other objects such as walls.
Consult with your dealer before a special installation such as suspending from a ceiling.

			4 : 3 screen					16 : 9 screen									
Scree (diag		Pr	() ojectior) n distar	ice	Scr	een	Scr	2) een	Pr	() ojectior	o) n distar	nce	Scr) een	Scr	2) een
land	onary	m	in.	ma	ax.	hei	ght	hei	ght	m	in.	ma	ax.	hei	ght	hei	ght
inch	m	m	inch	m	inch	cm	inch	cm	inch	m	inch	m	inch	cm	inch	cm	inch
30	0.8	0.9	34	1.1	41	41	16	5	2	1.0	38	1.1	45	39	15	-1	0
40	1.0	1.2	46	1.4	56	55	22	6	2	1.3	50	1.5	61	51	20	-2	-1
50	1.3	1.5	58	1.8	70	69	27	8	3	1.6	63	1.9	76	64	25	-2	-1
60	1.5	1.8	70	2.1	84	82	32	9	4	1.9	76	2.3	91	77	30	-2	-1
70	1.8	2.1	81	2.5	98	96	38	11	4	2.3	89	2.7	107	90	35	-3	-1
80	2.0	2.4	93	2.8	112	110	43	12	5	2.6	102	3.1	122	103	41	-3	-1
90	2.3	2.7	105	3.2	126	123	49	14	5	2.9	115	3.5	138	116	46	-4	-1
100	2.5	3.0	117	3.6	140	137	54	15	6	3.2	127	3.9	153	129	51	-4	-2
120	3.0	3.6	140	4.3	169	165	65	18	7	3.9	153	4.7	184	154	61	-5	-2
150	3.8	4.5	176	5.4	211	206	81	23	9	4.9	192	5.8	230	193	76	-6	-2
200	5.1	6.0	235	7.2	282	274	108	30	12	6.5	256	7.8	307	257	101	-8	-3
250	6.4	7.5	294	9.0	353	343	135	38	15	8.1	320	9.8	384	322	127	-10	-4
300	7.6	9.0	352	10.8	423	411	162	46	18	9.8	384	11.7	461	386	152	-12	-5

Arrangement (continued)

▲ **WARNING** ► Place the projector in a stable horizontal position. If the projector falls or is knocked over it could cause injury and/or damage to the projector. Using a damaged projector could then result in fire and/or electric shock.

- Do not place the projector on an unstable, slanted or vibrational surface such as a wobbly or inclined stand.
- Do not place the projector on its side, front or rear position.
- Consult with your dealer before a special installation such as suspending from a ceiling.

► Place the projector in a cool place, and ensure that there is sufficient ventilation. The high temperature of the projector could cause fire, burns and/or malfunction of the projector.

- Do not stop-up, block or otherwise cover the projector's vents.
- Keep a space of 30 cm or more between the sides of the projector and other objects such as walls.
- Do not place the projector on metallic thing or anything weak in heat.
- Do not place the projector on carpet, cushions or bedding.
- Do not place the projector in direct sunlight or near hot objects such as heaters.
- Do not anything near the projector lens or vents, or on top of the projector.
- Do not place anything that may be sucked into or stick to the vents on the bottom of the projector. This projector has some intake vents also on the bottom.

► Do not place the projector anyplace where it may get wet. Getting the projector wet or inserting liquid into the projector could cause fire, electric shock and/or malfunction of the projector.

- Do not place the projector in a bathroom or the outdoors.
- Do not place anything containing liquid near the projector.


▲ **CAUTION** ► Avoid placing the projector in smoky, humid or dusty place. Placing the projector in such places could cause fire, electric shock and/or malfunction of the projector.

• Do not place the projector near humidifiers, smoking spaces or a kitchen.

► Position the projector to prevent light from directly hitting the projector's remote sensor.


Connecting your devices

Be sure to read the manuals for devices before connecting them to the projector. Make sure that all the devices are suitable to be connected with this product, and prepare the cables required to connect. Please refer to the following illustrations to connect them.



Connecting your devices (continued)

To use MIU (Multi Information processing Unit) function, please connect at least one of the devices drawn in the following illustration to the projector.



▲ WARNING ► Do not disassemble or modify the projector and accessories.
 ► Be careful not to damage the cables, and do not use damaged cables.

▲ **CAUTION** ► Turn off all devices and unplug their power cords prior to connecting them to projector. Connecting a live device to the projector may generate extremely loud noises or other abnormalities that may result in malfunction or damage to the device and the projector.

► Use appropriate accessory or designated cables. Ask your dealer about nonaccessory cables which may be required a specific length or a ferrite core by the regulations. For cables with a core only at one end, connect the end with the core to the projector.

► Make sure that devices are connected to the correct ports. An incorrect connection may result in malfunction or damage to the device and the projector.

Connecting your devices (continued)

NOTE • Be sure to read the manuals for devices before connecting them to the projector, and make sure that all the devices are suitable to be connected with this product. Before connecting to a PC, check the signal level, the signal timing, and the resolution.

- Be sure to consult to the administrator of the network. Do not connect LAN port to any network that might have the excessive voltage.
- Some signal may need an adapter to input this projector.
- Some PCs have multiple screen display modes that may include some signals which are not supported by this projector.
- Although the projector can display signals with resolution up to UXGA (1600X1200), the signal will be converted to the projector's panel resolution before being displayed. The best display performance will be achieved if the resolutions of the input signal and the projector panel are identical.

• While connecting, make sure that the shape of the cable's connector fits the port to connect with. And be sure to tighten the screws on connectors with screws.

When connecting a laptop PC to the projector, be sure to activate the PC's external RGB output. (Set the laptop PC to CRT display or to simultaneous LCD and CRT display.) For details on how this is done, please refer to the instruction manual of the corresponding laptop PC.
When the picture resolution is changed on a PC depending on an input, automatic adjustment function may take some time and may not be completed. In this case, you may not be able to see a check box to select "Yes/No" for the new resolution on Windows. Then the resolution will go back to the original. It might be recommended to use other CRT or LCD monitors to change the resolution.

• In some cases, this projector may not display a proper picture or display any picture on screen. For example, automatic adjustment may not function correctly with some input signals. An input signal of composite sync or sync on G may confuse this projector, so the projector may not display a proper picture.

• The HDMI port of this model is compatible with HDCP (High-bandwidth Digital Content Protection) and therefore capable of displaying a video signal from HDCP compatible DVD players or the like.

About Plug-and-Play capability

Plug-and-Play is a system composed of a PC, its operating system and peripheral equipment (i.e. display devices). This projector is VESA DDC 2B compatible. Plug-and-Play can be used by connecting this projector to a PC that is VESA DDC (display data channel) compatible. • Take advantage of this feature by connecting an RGB cable to the COMPUTER IN1 port (DDC 2B compatible). Plug-and-Play may not work properly if any other type of connection is attempted.

• Please use the standard drivers in your PC as this projector is a Plug-and-Play monitor.

NOTE for HDMI

• The HDMI supports the following signals.

-Video signal : 525i(480i),525p(480p),625i(576i),750p(720p),1125i(1080i),1125p(1080p) -PC signals : See User's Manual (detailed) Technical

-Audio signal : Format Linear PCM

Sampling Frequency 48kHz / 44.1kHz / 32kHz

• This projector can be connected with another equipment that has HDMI or DVI connector, but with some equipment the projector may not work properly, something like no video or no audio.

• Be sure to use an HDMI cable that has the HDMI logo.

• When the projector is connected with a device having DVI connector, use a DVI to HDMI cable to connect with the HDMI input and an audio cable to connect with one of the Audio input.

Connecting your devices (continued)


Using a USB storage

In order to view images stored in a USB storage, such as a USB memory, insert the device into the USB STORAGE slot.

Before removing the USB storage, be sure to perform the REMOVE MEDIA procedure using the PC-LESS PRESENTATION menu under the MIU menu.

Using an SD card

In order to view images stored in an SD storage, such as an SD memory card, insert the device into the SD card slot. Or, in order to use the wireless network function, load the internal clock battery (168) and insert the designated wireless network card into the SD card slot.



Inserting the SD card

- Make sure that the power code is not plugged into
- 1. the projector for the wireless network card only.
- Remove the SD card slot cover. To remove it, it might be recommended to hook the
- 2. Remove the OD card and edge of its side face upward.
- Slowly insert the SD card completely into the SD card slot. Make sure that the angled
- 3. Slowly insert the SD card is placed into the right side of the SD card slot, while inserting.
- Replace the SD card slot cover. It is recommended that the cover is slid sideways to 4. the projector.

Using the slot cover lock for security

Using the enclosed slot cover lock can prevent the SD card slot cover from being opened.

- Open the two plates of the slot cover lock to put the tips of two plates together, and then insert the
- 1. Upen the two places of the SD card slot cover.
- Put the body of the two plates together. Then, hook a padlock or combination lock to
- 2. the hole of the slot cover lock.

Removing the SD card

- Perform the REMOVE MEDIA procedure using the PC-LESS PRESENTATION menu 1. under the MIU menu for SD Storage card only.
- Turn the projector off and unplug the power code from the projector for the wireless
- 2. <u>network card only.</u>
- 3. slot cover. Remove the SD card slot cover. After taking the SD card away, replace the SD card
- ▲ **WARNING** ► Do not disassemble or modify the projector and accessories. Do not touch the SD card while being accessed.

► The designated wireless network card that is sold as an option is required to use the wireless network function of this projector.


The wireless network card is not permitted to be sold or used in some countries and regions. Use the card only in the country or region where you buy it. For more information, contact to your dealer.

NOTE • When using the projector with a wired LAN, please remove the wireless network card.

Connecting power supply

At first, make sure that the power switch of the projector is set to OFF position (marked "O").

- 1 Put the connector of the power cord into the
- 1. AC inlet of the projector.
- 2 Firmly plug the power cord's plug into the
- 2. outlet.



AC inlet Power cord

▲ **WARNING** ► Please use extra caution when connecting the power cord, as incorrect or faulty connections may result in fire and/or electrical shock.

• Only use the power cord that came with the projector. If it is damaged, contact your dealer to newly get correct one.

• Only plug the power cord into an outlet whose voltage is matched to the power cord. The power outlet should be close to the projector and easily accessible. Remove the power cord for complete separation.

• Never modify the power cord.

Using the security bar and slot

A commercial anti-theft chain or wire up to 10 mm in diameter can be attached to the security bar on the projector.

Also this product has the security slot for the Kensington lock.

For details, see the manual of the security tool.

Anti-theft chain or wire



 \triangle **WARNING** \triangleright Do not use the security bar and slot to prevent the projector from falling down, since it is not designed for it.

 \triangle **CAUTION** \triangleright Do not place anti-theft chain or wire near the exhaust vents. It may become too hot.


NOTE • The security bar and slot is not comprehensive theft prevention measures. It is intended to be used as supplemental theft prevention measure.

Remote control

Putting batteries

Please set the batteries to the remote control before using it. If the remote control starts to malfunction, try to replace the batteries. If you will not use the remote control for long period, remove the batteries from the remote control and store them in a safe place.

- 1 Holding the hook part of the battery
- 1. cover, remove it.
- 2. Align and insert the two AA batteries (HITACHI MAXELL, Part No.LR6 or R6P)
- (HITACHI MAXELL, Part No.LR6 or R6P) according to their plus and minus terminals as indicated in the remote control.



3. Replace the battery cover in the direction of the arrow and snap it back into place.

▲ **WARNING** ► Always handle the batteries with care and use them only as directed. Improper use may result in battery explosion, cracking or leakage, which could result in fire, injury and/or pollution of the surrounding environment.

• Be sure to use only the batteries specified. Do not use batteries of different types at the same time. Do not mix a new battery with used one.

- Make sure the plus and minus terminals are correctly aligned when loading a battery.
- Keep a battery away from children and pets.
- Do not recharge, short circuit, solder or disassemble a battery.
- Do not allow a battery in a fire or water. Keep batteries in a dark, cool and dry place.
- If you observe battery leakage, wipe out the leakage and then replace a battery. If the leakage adheres to your body or clothes, rinse well with water immediately.
- Obey the local laws on disposing the battery.
- Obey the local laws on disposing the battery.

About the remote control signal

The remote control works with the projector's remote sensor. This projector has a remote sensor on the front. The sensor senses the signal within the following range when the sensor is active:

60 degrees (30 degrees to the left and right of the sensor) within 3 meters about.



NOTE • The remote control signal reflected in the screen or the like may be available.
If it is difficult to send the signal to the sensor directly, attempt to make the signal reflect.
The remote control uses infrared light to send signals to the projector (Class 1 LED), so be sure to use the remote control in an area free from obstacles that could block the remote control's signal to the projector.
The remote control may not work correctly if strong light (such as direct sup.)

• The remote control may not work correctly if strong light (such as direct sun light) or light from an extremely close range (such as from an inverter fluorescent lamp) shines on the remote sensor of the projector. Adjust the position of projector avoiding those lights.

0000

 \bigcirc Õlõõlõ

Changing the frequency of remote control signal

The accessory remote control has the two choices on signal frequency Mode 1:NORMAL and Mode 2:HIGH. If the remote control does not function properly, attempt to change the signal frequency. In order to set the Mode, please keep pressing the combination of two buttons listed below simultaneously for about 3 seconds.

(1) Set to Mode 1:NORMAL... MUTE and RESET buttons

(2) Set to Mode 2:HIGH... MAGNIFY OFF and ESC buttons

Please remember that the REMOTE FREQ, in the SERVICE item of the OPTION menu (446) of the projector to be controlled should be set to the same mode as the remote control.

Using as a simple PC mouse & keyboard

The accessory remote control works as a simple mouse and keyboard of the PC, when the projector's USB port (B type) connects with the PC's USB port (A type) port via a mouse cable.

- (1) HOME key: Press HOME button.
- (2) END key: Press END button.
- (3) PAGE UP key: Press PAGE UP button.
- (4) PAGE DOWN key: Press PAGE DOWN button.
- (5) Mouse left button: Press ENTER button.
- (6) Move pointer: Use the cursor buttons \blacktriangle , \triangledown , \triangleleft and \triangleright .
- (7) ESC key: Press ESC button.
- (8) Mouse right button: Press RESET button.

 \triangle **WARNING** \triangleright Improper use of the simple mouse & keyboard function could damage your equipment. While using this function, please connect this product only to a PC. Be sure to check your PC's manuals before connecting this product to the PC.

NOTE • When the simple mouse & keyboard function of this product does not work correctly, please check the following.

- When a USB cable connects this projector with a PC having a built-in pointing device (e.g. track ball) like a notebook PC, open BIOS setup menu, then select the external mouse and disable the built-in pointing device, because the built-in pointing device may have priority to this function.

- Windows 95 OSR 2.1 or higher is required for this function. And also this function may not work depending on the PC's configurations and mouse drivers.

- You cannot do things like press two buttons at once (for instance, pressing two buttons at the same time to move the mouse pointer diagonally).

- This function is activated only when the projector is working properly. This function is not available while the lamp is warming up (the POWER indicator blinks green), and while adjusting the volume and display, correcting for keystone, zooming in on the screen, using the BLANK function, or displaying the menu screen.

http://www.pureglare.com.au



(5)

(7)

-(6)

(8)

Power on/off

Turning on the power

- Make sure that the power cord is firmly and correctly
- connected to the projector and the outlet.
- Remove the lens cover, and set the power switch to
- 2. ON position (marked "I"). The POWER indicator will light up in steady orange (171). Then wait several seconds because the buttons may not function for these several seconds.
- Press STANDBY/ON button on the projector or the
- 3. remote control. The projection lamp will light up and POWER indicator will begin blinking in green. When the power is completely on, the indicator will stop blinking and light in steady green (171).

To display the picture, select an input signal according to the section "Selecting an input signal" (117).

Turning off the power

- Press the STANDBY/ON button on the projector or the remote control. The message
- 1. "Power off?" will appear on the screen for about 5 seconds.
- Press the STANDBY/ON button again while the message appears.
- 2. Press the STANDBY/ON button again while the model of appendix. The projector lamp will go off, and the POWER indicator will begin blinking in orange. Then POWER indicator will stop blinking and light in steady orange when the lamp cooling is complete ($\square 71$).
- 3. Make sure that FOWER more than the lens Make sure that POWER indicator lights in steady orange, and set the

POWER indicator will go off. Attach the lens cover.

Do not turn the projector on for about 10 minutes or more after turning it off. Turning the projector on again too soon could shorten the lifetime of some consumable parts of the projector.

▲ **WARNING** ► A strong light is emitted when the projector's power is on. Do not look into the lens of the projector or look inside of the projector through any of the projector's openings.


Do not touch around the lamp cover and the exhaust vents during use or just after use, since it is too hot.

NOTE • Turn the power on/off in right order. Please power on the projector prior to the connected devices.

• When the AUTO ON of the OPTION menu is set to the TURN ON, and the power was turned off by the power switch last time, turning the power switch on makes the projection lamp light on without pushing the STANDBY/ON button (242).

• Use the shutdown switch (172) only when the projector is not turned off by normal procedure.





Power switch



Power switch

VOI UMF button

Operating

Adjusting the volume

- Press VOLUME button on the remote control.
- 1. A dialog will appear on the screen to aid you in adjusting the volume.
- Use the \blacktriangle/∇ cursor buttons to adjust the volume.
- 2. Use the A/V cursor buttons to adjust the volume. To close the dialog and complete the operation, press the VOLUME button again. Even if you do not do anything, the dialog will automatically disappear after a few seconds.
 - When X is selected for current picture input port, the volume adjustment is disable. Please see AUDIO item of SETUP menu (437).

Temporarily muting the sound

- Press MUTE button on the remote control.
- A dialog will appear on the screen indicating that you have muted the sound. To restore the sound, press the MUTE or VOLUME button. Even if you do not do anything, the dialog will automatically disappear after a few seconds.
 - When X is selected for current picture input port, the sound is always muted. Please see AUDIO item of SETUP menu (137).
 - When 🕱 is selected to VIDEO or S-VIDEO port, the C.C. (Closed Caption) is automatically activated if the C.C. is set to AUTO in the DISPLAY of the C.C. menu and the input signal from the port supports the C.C. feature (

Selecting an input signal

- Press INPUT button on the projector.
- Each time you press the button, the projector switches its input port from the current port as below.


 \rightarrow COMPUTER IN 1 \rightarrow COMPUTER IN 2 \rightarrow HDMI \rightarrow MIU -- VIDEO ← S-VIDEO ← COMPONENT (Y, Cb/Pb, Cr/Pr) ←


- While TURN ON is selected for AUTO SEARCH item in OPTION menu (**4**2), the projector will keep checking the ports in above order repeatedly till an input signal is detected.
- Press COMPUTER button on the remote control.
- Each time you press the button, the projector switches its input port from the current port as below.

 \rightarrow COMPUTER IN 1 \rightarrow COMPUTER IN 2 \rightarrow HDMI \rightarrow MIU


 While TURN ON is selected for AUTO SEARCH item in OPTION menu, the projector will keep checking every port sequentially till an input signal is detected (442). If COMPUTER button is pushed when VIDEO, S-VIDEO or COMPONENT port is selected, the projector will check COMPUTER IN1 port first.

(continued on next page)






button



INPUT button



COMPUTER button



http://www.pureglare.com.au

Selecting an input signal (continued)

- Press VIDEO button on the remote control.
- Each time you press the button, the projector switches its input port from the current port as below.

COMPONENT (Y, Cb/Pb, Cr/Pr) \rightarrow S-VIDEO \rightarrow VIDEO

 While TURN ON is selected for AUTO SEARCH item in OPTION menu, the projector will keep checking every port sequentially till an input signal is detected ($\square 42$). If VIDEO button is pushed when COMPUTER IN1, COMPUTER IN2, HDMI or MIU port is selected, the projector will check COMPONENT port first.

Searching an input signal

Press SEARCH button on the remote control.

- The projector will start to check its input ports as below in order to find any input signals.

When an input is found, the projector will stop searching and display the image. If no signal is found, the projector will return to the state selected before the operation.

 \rightarrow COMPUTER IN 1 \rightarrow COMPUTER IN 2 \rightarrow HDMI \rightarrow MIU - \checkmark VIDEO \leftarrow S-VIDEO \leftarrow COMPONENT (Y, Cb/Pb, Cr/Pr) \leftarrow

- While TURN ON is selected for AUTO SEARCH item in OPTION menu (442), the projector will keep checking the ports in above order repeatedly till an input signal is detected.
- The MIU input is skipped, as long as no image is sent from PC on the "Live Mode" of MIU (**153**).

Selecting an aspect ratio

- Press ASPECT button on the remote control.
- 1. Each time you press the button, the projector switches the mode for aspect ratio in turn.
 - O For a computer signal or MIU signal NORMAL \rightarrow 4:3 \rightarrow 16:9 \rightarrow SMALL \wedge
 - **O** For a HDMI signal NORMAL \rightarrow 4:3 \rightarrow 16:9 \rightarrow 14:9 \rightarrow SMALL

O For a video signal, s-video signal or component video signal $4:3 \rightarrow 16:9 \rightarrow 14:9 \rightarrow SMALL$

O For no signal 4:3 (fixed)

- ASPECT button does not work when no proper signal is inputted.
- NORMAL mode keeps the original aspect ratio setting.

SEARCH button





ASPECT button



VIDFO button

Pure Glare

Adjusting the projector's elevator

When the place to put the projector is slightly uneven to the left or right, use the elevator feet to place the projector horizontally.

Using the feet can also tilt the projector in order to project at a suitable angle to the screen, elevating the front side of the projector within 10 degrees.

This projector has 2 elevator feet and 2 elevator buttons. An elevator foot is adjustable while pushing the elevator button on the same side as it.

- 1 Holding the projector, push the elevator buttons to loose the elevator feet.
- **2** Position the front side of the projector to the desired height.
- ${\bf 3}$ Release the elevator buttons in order to lock the elevator feet.
- 4 After making sure that the elevator feet are locked, put the projector gently.
- 5. If necessary, the elevator feet can be manually twisted to make more precise adjustments. Hold the projector when twisting the feet.


To loose an elevator foot, push the elevator button on the same side as it.

▲ **CAUTION** ► Do not handle the elevator buttons without holding the projector, since the projector may drop down.

► Do not tilt the projector other than elevating its front within 10 degrees using the adjuster feet. A tilt of the projector exceeding the restriction could cause malfunction or shortening the lifetime of consumables, or the projector itself.

Adjusting the zoom and focus

- **1** Use the zoom ring to adjust the screen size.
- **7** Use the focus ring to focus the picture.









Using the automatic adjustment feature

- Press AUTO button on the remote control.
- Pressing this button performs the following.
 - O For a computer signal or MIU signal

The vertical position, the horizontal position and the horizontal phase will be automatically adjusted. Make sure that the application window is set to its maximum size prior to attempting to use this feature. A dark picture may still be incorrectly adjusted. Use a bright picture when adjusting.

O For a video signal and s-video signal

The video format best suited for the respective input signal will be selected automatically. This function is available only when the AUTO is selected for the VIDEO FORMAT item in the INPUT menu (133). The vertical position and horizontal position will be automatically set to the default.

O For a component video signal

The vertical position, horizontal position and horizontal phase will be automatically set to the default.

- The automatic adjustment operation requires approx. 10 seconds. Also please note that it may not function correctly with some input. When this function is performed for a video signal, a certain extra such as a line may appear outside a picture.
- The items adjusted by this function may vary when the FINE or DISABLE is selected for the AUTO ADJUST item of the SERVICE item in the OPTION menu (**45**).

Adjusting the position


Press POSITION button on the remote control when no menu is indicated.

The "POSITION" indication will appear on the screen.

- Use the $\blacktriangle/ \bigtriangledown / \checkmark / \checkmark /$ cursor buttons to adjust the picture position.
- 2. Use the A/V/A/P cursor button to act, when you want to reset the operation, press RESET button on the remote control during the operation. To complete this operation, press POSITION button again.

Even if you do not do anything, the dialog will automatically **POSITION** button disappear after a few seconds.

- When this function is performed on a video signal, s-video signal or component video signal, some image such as an extra-line may appear at outside of the picture.
- If POSITION button is pressed when a menu is indicated on screen, the displayed picture does not move its position but the menu does.





KEYSTONE button

Correcting the keystone distortions

- Press KEYSTONE button on the remote
- control. A dialog will appear on the screen to aid you in correcting the distortion.
- Use the ▲/▼ cursor buttons to select AUTO or MANUAL
- 2. Ose the \land v cursor button to perform the operation, and press the \triangleright button to perform the following.
 - (1) AUTO executes automatic vertical keystone correction.
 - (2) MANUAL displays a dialog for keystone correction. Use the cursor buttons $\triangleleft/\triangleright$ to select the direction to correct (\square or \square) then use the \blacktriangle/∇ buttons for adjustment.

To close the dialog and complete this operation, press KEYSTONE button again. Even if you do not do anything, the dialog will automatically disappear after a few seconds.

The adjustable range of this correction will vary among inputs. For some input, this function may not work well.

Pure Glare

- When V:INVERT or H&V:INVERT is selected to the MIRROR item in the SETUP menu, if the projector screen is inclined or angled downward, this function may not work correctly.
- When the zoom adjustment is set to the TELE (telephoto focus), the automatic keystone distortion correction may be excessive. This function should be used when the zoom adjustment is set to the full WIDE (wide-angle focus) whenever possible.
- When the projector is placed on the level (about ±3°), the automatic keystone distortion correction may not work.
- When the projector is inclined to near ±30 degree or over, this function may not work well.
- This function will be unavailable when Transition Detector is on (151).

Using the magnify feature

- Press the ON button of MAGNIFY on the remote control.
- 1. The "MAGNIFY" indication will appear on the screen and the projector will go into the MAGNIFY mode. When the ON button of MAGNIFY is pressed first after the projector is started, the picture will be zoomed twice. The indication will disappear in several seconds with no operation.
- Use the \blacktriangle/∇ cursor buttons to adjust the zoom level. The picture of

2. Use the A/V cursor buttons to adjust the ______ video, s-video or component video signal can be zoomed in up to 2 times, and the one of computer signal can be zoomed in up to 4 times. To move the zoom area, press the POSITION button in the MAGNIFY mode, then use the $\blacktriangle/ \bigtriangledown/ \lt/ \lor$ cursor buttons to move the area. And to finalize the zoom area, press the POSITION button again.


To exit from the MAGNIFY mode and restore the screen to normal, press the OFF button of MAGNIFY on the remote control.

- The projector automatically exits from the MAGNIFY mode when the input signal is changed or when the display condition is changed.
- In the MAGNIFY mode, the keystone distortion condition may vary, it will be restored when the projector exits from the MAGNIFY mode.

NOTE • The zoom level can be finely adjusted. Closely watch the screen to find the level you want.

MAGNIFY **ON/OFF** button







22

Freezing the screen

- Press the FREEZE button on the remote control.
- 1. The "FREEZE" indication will appear on the screen (however, the indication will not appear when the TURN OFF is selected for the MESSAGE item in the SCREEN menu (41). and the projector will go into the FREEZE mode, which the picture is frozen.

To exit the FREEZE mode and restore the screen to normal. press the FREEZE button again.

- The projector automatically exits from the FREEZE mode when one of the projector's buttons or remote control buttons of STANDBY/ON, SEARCH, COMPUTER, VIDEO, BLANK, AUTO, VOLUME, MUTE, KEYSTONE, MENU, MAGNIFY and MY BUTTON1/2 (except MY MEMORY or PICTURE MODE is assigned to) ($\square 44$) is pressed.
- If the projector continues projecting a still image for a long time, the LCD panel might possibly be burned in. Do not leave the projector in the FREEZE mode for too long.

Temporarily blanking the screen


- Press BLANK button on the remote control.
 - The BLANK screen will be displayed instead of the screen of input signal. Please refer to BLANK item in SCREEN menu (238).

To exit from the BLANK screen and return to the input signal screen, press BLANK button again.

• The projector automatically returns to the input signal screen when one of the projector's buttons or the remote control buttons (except ASPECT, POSITION, MAGNIFY or FREEZE button, also except MY BUTTON1/2 if AUTO KEYSTONE or MY MEMORY or PICTURE MODE is assigned to (44)) is pressed.

NOTE • The sound is not connected with the BLANK screen function. If necessary, set the volume or mute first,

OPureGlare





BI ANK button


Using the menu function

This projector has the following menus:

PICTURE, IMAGE, INPUT, SETUP, SCREEN, OPTION, MIU, C.C. and EASY MENU.

EASY MENU consists of functions often used, and the other menus are classified into each purpose and brought together as the Advanced Menu.

Each of these menus is operated using the same methods. The basic operations of these menus are as follows.



- Press the MENU button on the remote control or the projector.
- 1. The Advanced Menu or EASY MENU, which has priority just after powered on will appear.

If you want to move the menu position, use the cursor buttons after pressing the POSITION button. While the projector is displaying any menu, the MENU button on the projector works as the cursor buttons.

In the EASY MENU

- If you want to change it to the Advanced Menu,
- select the Go to Advanced Menu...
- Use the \blacktriangle/∇ cursor buttons to select an item to **3.** operate.
- Use the $\triangleleft/\triangleright$ cursor buttons to operate the item. Δ



EASY MENU

Using the menu function (continued)

In the Advanced Menu

- Use the \blacktriangle/∇ cursor buttons to select a menu.
- 2. Use the ▲/ ▼ cursor buttons to change it to the EASY MENU, select EASY MENU.

Then press the ► cursor button, or ENTER button to select an item. The lower layer menu of the selected item will appear.

MENU [COMPUT	:SELECT	
PICTURE	BRIGHTNESS	+0
IMAGE	CONTRAST	+0
INPUT	GAMMA	DEFAULT-1
SETUP	COLOR TEMP	HIGH
SCREEN	COLOR	+0
OPTION	TINT	+0
MIU	SHARPNESS	4
C.C.	MY MEMORY	SAVE-1
EASY MENU		

Advanced Menu

- Use the \blacktriangle/∇ cursor buttons to select an item to operate.
- 3. Use the \blacktriangle v cursor button, or ENTER button to progress. The operation menu of the selected item will appear.
- Use the \blacktriangle/∇ cursor buttons to operate the item. 4
 - Some functions cannot be performed when a certain input port is selected, or when a certain input signal is displayed.
 - When you want to reset the operation, press RESET button on the remote control during the operation. Note that some items (ex. LANGUAGE, H PHASE, VOLUME) cannot be reset.
 - In the Advanced Menu, when you want to return to the previous display, press the < cursor button or ESC button on the remote control.
- Press MENU button on the remote control again to close the menu and 5. complete this operation. Even if you do not do anything, the dialog will automatically disappear after about 10 seconds.

EASY MENU

EASY MENU

From the EASY MENU, items shown in the table below can be performed. Select an item using the \blacktriangle/\lor cursor buttons. Then

perform it according to the following table.

EASY MENU [COM	IPUT	ER 1]	
ASPECT	4	4:3	D
AUTO KEYSTON			
KEYSTONE 🔿		-	0
KEYSTONE		+	0
PICTURE MODE		NORMAL	
BRIGHTNESS			0
CONTRAST			0
COLOR			0
TINT			0
SHARPNESS			4
WHISPER		NORMAL	
MIRROR		NORMAL	
RESET		EXECUTE	
FILTER TIME		0h	
LANGUAGE	D	ENGLISH	
Got	to A	dvanced Menu	l

Item		Description		
ASPECT	Using the ◄/ ► buttons switches the mode for aspect ratio. See the ASPECT item in IMAGE menu (□ 30).			
	Using the ► button executes the auto keystone function. See AUTO KEYSTONE (EXECUTE item in SETUP menu (35).			
	Using the ◀/► butto See KEYSTONE /	ons corrects the vertical ke item in SETUP menu (ystone distortion. 35).	
KEYSTONE 🔇		ons corrects the horizontal		
PICTURE MODE	See the KEYSTONE ⊆ item in SETUP menu (☐35). Using the buttons switches the picture mode. The picture modes are combinations of GAMMA and COLOR TEMP settings. Choose a suitable mode according to the projected source. NORMAL ⇔ CINEMA ⇔ DYNAMIC ⇔ BOARD(BLACK) ← DAYTIME ⇔ WHITEBOARD ⇔ BOARD(GREEN) ← COLOR TEMP GAMMA NORMAL #2 MID DEFAULT #1 DEFAULT CINEMA #3 LOW DEFAULT #2 DEFAULT DAYNAMIC #1 HIGH DEFAULT #3 DEFAULT BOARD(BLACK) #4 Hi-BRIGHT-1 DEFAULT #4 DEFAULT BOARD(BLACK) #4 Hi-BRIGHT-2 DEFAULT #4 DEFAULT WHITEBOARD #2 MID DEFAULT #5 DEFAULT When the combination of GAMMA and COLOR TEMP differs from pre-assigned modes above, the display on the menu for the			
	 PICTURE MODE is "CUSTOM". Please refer to GAMMA (27) and COLOR TEMP (28) items in PICTURE menu. When this function is performed, a certain extra such as a line may appear. 			

EASY MENU (continued)

Item	Description
BRIGHTNESS	Using the ◀/▶ buttons adjusts the brightness. See BRIGHTNESS item in PICTURE menu ([□] 27).
CONTRAST	Using the ◄/ ▶ buttons adjusts the contrast. See CONTRAST item in PICTURE menu (127).
COLOR	Using the ◄ /▶ buttons adjusts the strength of whole color. See COLOR item in PICTURE menu (□28).
TINT	Using the ◄/ ► buttons adjusts the tint. See TINT item in PICTURE menu (□28).
SHARPNESS	Using the ◄/▶ buttons adjusts the sharpness. See SHARPNESS item in PICTURE menu (□29).
WHISPER	Using the ◄ /▶ buttons turns off/on the whisper mode. See WHISPER item in SETUP menu (□ 36).
MIRROR	Using the $\triangleleft/\triangleright$ buttons switches the mode for mirror status. See MIRROR item in SETUP menu ($\square 36$).
RESET	Performing this item resets all of EASY MENU items except FILTER TIME and LANGUAGE. A dialog is displayed for confirmation. Selecting RESET using the button performs resetting.
FILTER TIME	The usage time of the air filter is shown in the menu. Performing this item resets the filter time which counts usage time of the air filter. A dialog is displayed for confirmation. Selecting RESET using the ▲ button performs resetting. See FILTER TIME item in OPTION menu (143).
LANGUAGE	Using the ◄/▶ buttons changes the display language. See LANGUAGE item in SCREEN menu (□ 38).
Go to Advanced Menu	Select Go to Advanced Menu on the menu, and press the ► or ENTER button to use the menu of PICTURE, IMAGE, INPUT, SETUP, SCREEN, OPTION, MIU or C.C

PICTURE menu

From the PICTURE menu, items shown in the table below can be performed.

Select an item using the \blacktriangle/∇ cursor buttons, and press the \blacktriangleright cursor button or ENTER button to execute the item. Then perform it according to the following table.

Item	Description				
BRIGHTNESS	Using the ▲/▼ buttons adjusts the brightness. Light ⇔ Dark				
CONTRAST	Using the ▲/▼ buttons adjusts the contrast. Strong ⇔ Weak				
	Using the $\blacktriangle/\blacksquare$ buttons switches the gamma mode.				
	#1 DEFAULT \Leftrightarrow #1 CUSTOM \Leftrightarrow #2 DEFAULT \Leftrightarrow #2 CUSTOM				
	#6 CUSTOM #3 DEFAULT				
	û #6 DEFAULT #3 CUSTOM				
	≎ #5 CUSTOM ⇔ #5 DEFAULT ⇔ #4 CUSTOM ⇔ #4 DEFAULT				
	To adjust CUSTOM				
GAMMA	Selecting a mode whose name includes CUSTOM and then pressing the ▶ button or the ENTER button displays a dialog to aid you in adjusting the mode. This function is useful when you want to change the brightness of particular tones. Choose an item using the ◄/▶ buttons, and adjust the level using the ▲/▼ buttons. You can display a test pattern for checking the effect of your				
	adjustment by pressing the ENTER button. Each time you press the ENTER button, the pattern changes as below.				
	No pattern ⇔ Gray scale of 9 steps —, î Ramp ⇔ Gray scale of 15 steps				
	The eight equalizing bars correspond to eight tone levels of the test pattern (Gray scale of 9 steps), except the darkest in the left end. If you want to adjust the 2nd tone from left end on the test pattern use the equalizing adjustment bar "1". The darkest tone at the left end of the test pattern cannot be controlled with any of equalizing adjustment bar. • When this function is performed, lines or other distortion may appear.				
continued on next of					

MENU [COMPL	JTER 1]	:SELECT
PICTURE	BRIGHTNESS	+0
IMAGE	CONTRAST	+0
INPUT	GAMMA	DEFAULT-1
SETUP	COLOR TEMP	HIGH
SCREEN	COLOR	+0
OPTION	TINT	+0
MIU	SHARPNESS	
C.C.	MY MEMORY	SAVE-1
EASY MENU		



PICTURE menu (continued)

Item	L	Description		
		thes the color temperature mode. H CUSTOM ⇔ #2 MID DEFAULT		
	û #6 Hi-BRIGHT-3 CUSTOM	#2 MID CUSTOM		
	û #6 Hi-BRIGHT-3 DEFAULT	#3 LOW DEFAULT		
	€ #5 Hi-BRIGHT-2 CUSTOM	#3 LOW CUSTOM		
	\$ #5 Hi-BRIGHT-2 DEFAULT ⇔ #4 Hi-BRIGH	ાT-1 CUSTOM ⇔ #4 Hi-BRIGHT-1 DEFAULT		
	To adjust CUSTOM			
COLOR TEMP	Selecting a mode whose name includes CUSTOM and then pressing the ► button or the ENTER button displays a dialog to aid you in adjusting the OFFSET and GAIN of the selected mode. OFFSET adjustments change the color intensity on the whole tones of the test pattern.			
	GAIN adjustments mainly aff on the brighter tones of the t	ect color intensity		
	Choose an item using the ◀ the ▲/▼ buttons.	✓ buttons, and adjust the level using		
	You can display a test pattern for checking the effect of your adjustment by pressing the ENTER button. Each time you press the ENTER button, the pattern changes as below.			
	No pattern ⇔ Gray scale of	9 steps 🖳		
	î Ê Ramp ⇔ Gray sca	le of 15 steps		
	• When this function is perfor appear.	med, lines or other distortion may		
COLOR	Using the ▲/▼ buttons adju Strong ⇔ Weak	sts the strength of whole color.		
COLOR	• This item can be selected only for a video signal, s-video, component video signal or HDMI signal.			
	Using the ▲/▼ buttons adju	sts the tint.		
TINT	Greenish ⇔ Reddish			
	• This item can be selected c component video signal or H	nly for a video signal, s-video, DMI signal.		

PICTURE menu (continued)

ltem	Description		
SHARPNESS	 Using the ▲/▼ buttons adjusts the sharpness. Strong ⇔ Weak There may be some noise and/or the screen may flicker for a moment when an adjustment is made. This is not a malfunction. 		
MY MEMORY	 This projector has 4 memories for adjustment data (for all the items of PICTURE menu). Selecting a function using the ▲/▼ buttons and pressing the ▶ or ENTER button performs each function. 		

IMAGE menu

From the IMAGE menu, items shown in the table below can be performed.

Select an item using the \blacktriangle/\lor cursor buttons, and press the \blacktriangleright cursor button or ENTER button to execute the item. Then perform it according to the following table.

MENU [COMPUT	:SELECT	
PICTURE	ASPECT	4:3
IMAGE	OVER SCAN	5
INPUT	V POSITION	25
SETUP	H POSITION	142
SCREEN	H PHASE	16
OPTION	H SIZE	1344
MIU	AUTO ADJUST EX	ECUTE
C.C.		
EASY MENU		

Item	Description
	Using the ▲/▼ buttons switches the mode for aspect ratio. For a computer signal or MIU signal NORMAL ⇔ 4:3 ⇔ 16:9 ⇔ SMALL 1 1
ASPECT	For an HDMI signal NORMAL ⇔ 4:3 ⇔ 16:9 ⇔ 14:9 ⇔ SMALL ℃
	For a Video signal, S-video signal or Component video signal 4:3 ⇔ 16:9 ⇔ 14:9 ⇔ SMALL
	 For no signal 4:3 (fixed) The NORMAL mode keeps the original aspect ratio of the signal.
	Using the ▲/▼ buttons adjusts the over-scan ratio. Large (It reduces picture) ⇔ Small (It magnifies picture)
OVER SCAN	 This item can be selected only for a video, s-vide, component video and HDMI signal. When this adjustment is too large, certain degradation may appear at the frame area of the picture. In such a case, please adjust small.
	Using the ▲/▼ buttons adjusts the vertical position.
V POSITION	Up ⇔ Down • The V POSITION can not be adjusted for signals from the HDMI port. • Over-adjusting the vertical position may cause noise to appear on the screen. If this occurs please reset the vertical position to the default setting. Pressing RESET button when V POSITION is selected will reset V POSITION to the default setting. • When this function is performed on a video signal, s-video signal, or component video signal, of 525i (480i) or 625i (576i) input from the COMPONENT port, the range of this adjustment depends on OVER SCAN (Mabove) setting. It is not possible to adjust when OVER SCAN is set to 10.

IMAGE menu (continued)

Item	Description
	Using the ▲/▼ buttons adjusts the horizontal position. Left ⇔ Right
H POSITION	 The H POSITION can not be adjusted for signals from the HDMI port. Over-adjusting the horizontal position may cause noise to appear on the screen. If this occurs please reset the horizontal position to the default setting. Pressing RESET button when H POSITION is selected will reset H POSITION to the default setting. When this function is performed on a video signal, s-video signal, or component video signal, of 525i (480i) or 625i (576i) input from the COMPONENT port, the range of this adjustment depends on OVER SCAN (Mabove) setting. It is not possible to adjust when OVER SCAN is set to 10.
	Using the \blacktriangle/\lor buttons adjusts the horizontal phase to eliminate flicker.
H PHASE	Right ⇔ Left • This item can be selected only for a computer signal, a MIU signal or component video signal. (except 525 (408i), 625i (576i), SCART RGB input from the COMPONENT port.)
	Using the \blacktriangle/∇ buttons adjusts the horizontal size.
H SIZE	Large ⇔ Small This item can be selected only for a computer signal or an MIU signal. When this adjustment is excessive, the picture may not be displayed correctly. In such a case, please reset the adjustment by pressing the RESET button during this operation.
AUTO ADJUST EXECUTE	Executing this item performs the automatic adjustment feature. For a computer signal or MIU signal The vertical position, the horizontal position and the horizontal phase (145) will be automatically adjusted. Make sure that the application window is set to its maximum size prior to attempting to use this feature. A dark picture may still be incorrectly adjusted. Use a bright picture when adjusting.
	For a video signal and s-video signal The video format best suited for the respective input signal will be selected automatically. This function is available only when the AUTO is selected for the VIDEO FORMAT item in the INPUT menu (1133). The vertical position and horizontal position will be automatically set to the default.
	For a component video signal The vertical position, horizontal position and horizontal phase will be automatically set to the default.
	 The automatic adjustment operation requires approx. 10 seconds. Also please note that it may not function correctly with some input. When this function is performed for a video signal, a certain extra such as a line may appear outside a picture. The items adjusted by this function may vary when the FINE or DISABLE is selected for the AUTO ADJUST item of the SERVICE item in the OPTION menu (145).



INPUT menu

From the INPUT menu, items shown in the table below can be performed.

Select an item using the \blacktriangle/\lor cursor buttons, and press the \blacktriangleright cursor button or ENTER button to execute the item. Then perform it according to the following table.

MENU [COMPUTER 1]		:SELECT
PICTURE	PROGRESSIVE	FILM
IMAGE	VIDEO NR	MID
INPUT	COLOR SPACE	AUTO
SETUP	COMPONENT	COMPONENT
SCREEN	VIDEO FORMAT	
OPTION	HDMI	AUTO
MIU	FRAME LOCK	
C.C.	COMPUTER IN	
EASY MENU	RESOLUTION	

Item	Description
PROGRESSIVE	 Using the ▲/▼ buttons switches the progress mode. TV ⇔ FILM ⇔ TURN OFF
VIDEO NR	 Using the ▲/▼ buttons switches the noise reduction mode. HIGH ⇔ MID ⇔ LOW
COLOR SPACE	 Using the ▲/▼ buttons switches the mode for color space. AUTO ⇔ RGB ⇔ SMPTE240 ⇔ REC709 ⇔ REC601 Image: the selected only for a computer signal or component video signal except SCART RGB signal. The AUTO mode automatically selects the optimum mode. The AUTO operation may not work well at some signals. In such a case, it might be good to select a suitable mode except AUTO.
COMPONENT	Using the ▲/▼ buttons switches the function of the COMPONENT (Y, Cb/Pb, Cr/Pr) port. COMPONENT ⇔ SCART RGB When the SCART RGB is selected, COMPONENT (Y, Cb/Pb, Cr/ Pr) and VIDEO ports will function as a SCART RGB port. A SCART cable is required for a SCART RGB input to the projector. For your reference, see the TECHNICAL part.

INPUT menu (continued)

ltem		Description
VIDEO FORMAT	 (1) Use the ◄/▶ butt (2) Using the ▲/▼ but for video format. AUTO ⇔ NTSC < È N-PAL ⇔ M-PA This item is perform from VIDEO port or S The AUTO mode au The AUTO operation may n 	ed only for a video signal
HDMI	AUTO ⇔ NORMAL L AUTO AUTO NORMAL ENHANCED	Feature Selecting the optimum mode automatically Suitable for DVD signals (16-235) Suitable for VGA signals (0-255) screen image is too strong or too weak, try
FRAME LOCK	 Set the frame lock function on/off for each port. (1) Using the ▲/▼ buttons to select one of following ports. COMPUTER(IN)1 ⇔ COMPUTER(IN)2 ⇔ HDMI (2) Using the ◄/► buttons to turns the frame lock function on/off. TURN ON ⇔ TURN OFF This item can be performed only on a signal with a vertical frequency of 50 to 60 Hz. When the TURN ON is selected, a moving pictures are displayed more smoothly. This function may cause a certain degradation of the picture. In such a case, please select TURN OFF. 	
COMPUTER IN	The computer input sign: (1) Use the ◀/▶ butt port to be set. COMPUTER (IN)1 (2) Use the ▲/▼ butt computer input sig SYNC ON G ON ⇔ Selecting SYNC ON C • When SYNC ON G O certain input signals. In	al type for COMPUTER IN1 and IN2 ports can be set. toons to select the input ⇔ COMPUTER (IN)2 toons to select the gnal type.



INPUT menu (continued)

Item	Description
	The resolution for the COMPUTER IN1 and IN2 input signals can be set on this projector. (1) In the INPUT menu select the RESOLUTION using the ▲/▼
	buttons and press the ► button. The RESOLUTION menu will be displayed.
	(2) In the RESOLUTION menu, select the resolution you wish to display using the ▲/▼ buttons. Selecting AUTO will set a resolution appropriate to the input signal.
	(3) STANDARD Pressing the ► or ENTER button when selecting a STANDARD resolution will automatically adjust the horizontal and vertical positions, clock phase and horizontal size and automatically select an aspect ratio. STANDARD ↓ COMPUTER 1 1280×768 @60Hz
RESOLUTION	 (3) CUSTOM (3) -1 To set a custom resolution use the A/▼ buttons to select the CUSTOM and the CUSTOM RESOLUTION box will be displayed. Set the horizontal (HORZ) and vertical (VERT) resolutions using the A/▼ / ◄/► buttons. It is not guaranteed to work this function properly on any resolutions.
	(3)-2 To save the setting place the cursor on the right-most digit and press the ► button. The horizontal and vertical positions, clock phase and horizontal size will
	be automatically adjusted. (3)-3 To revert back to the previous resolution without saving changes place the cursor on the left-most digit and press the ◀ button. The screen will then return to the RESOLUTION menu displaying the previous resolution.
	For some pictures, this function may not work well.

SETUP menu

From the SETUP menu, items shown in the table below can be performed.

Select an item using the \blacktriangle/∇ cursor buttons, and press the \triangleright cursor button or the ENTER button to execute the item. Then perform it according to the following table.

MENU [COMPUT	ER 1J	C:SELECT
PICTURE	AUTO KEYSTON	IE 🗥 EXECUTE
IMAGE	KEYSTONE 🗥	+0
INPUT	KEYSTONE	+0
SETUP	WHISPER	NORMAL
SCREEN	MIRROR	NORMAL
OPTION	VOLUME	16
MIU	SPEAKER	TURN ON
C.C.	AUDIO	
EASY MENU	HDMI AUDIO	

Item	Description
AUTO KEYSTONE 🔼 EXECUTE	Selecting this item performs the automatic keystone distortion correction. Projector automatically corrects vertical keystone distortion due to the (forward/backward) setup angle by itself.
	This function will be executed only once when selected in the menu. When the slant of the projector is changed, execute this function again.
	 The adjustable range for correction will vary among inputs. For some input, this function may not work well. When V:INVERT or H&V:INVERT is selected to the MIRROR item in the SETUP menu, if the projector screen is inclined or angled
	 downward, this function may not work correctly. When the zoom adjustment is set to the TELE (telephoto focus), this function may be excessive. This function should be used when the zoom adjustment is set to the full WIDE (wide-angle focus) whenever possible.
	 When the projector is placed on the level (about ±3°), this function may not work.
	 When the projector is inclined to near ±30 degree or over, this function may not work well.
	 This function will be unavailable when the Transition Detector is on (<u>151</u>).
	Using the ▲/▼ buttons corrects the vertical keystone distortion.
	Shrink the top of the image ⇔ Shrink the bottom of the image
	 The adjustable range of this function will vary with the type of input signal. For some input, this function may not work well. This function will be unavailable when the Transition Detector is on (151).
	Using the ▲/▼ buttons corrects the horizontal keystone distortion.
	Shrink the right of the image ⇔ Shrink the left of the image
	 The adjustable range of this function will vary among inputs. For some input, this function may not work well. When the zoom adjustment is set to the TELE (telephoto focus), this function may be excessive. This function should be used when the zoom adjustment is set to the full WIDE (wide-angle focus) whenever possible.
	• This function will be unavailable when the Transition Detector is on (11 51).



SETUP menu (continued)

Item	Description
WHISPER	 Using the ▲/▼ buttons turns off/on the whisper mode. NORMAL ⇔ WHISPER When WHISPER is selected, acoustic noise and screen brightness are reduced.
MIRROR	Using the ▲/▼ buttons switches the mode for mirror status. NORMAL ⇔ H:INVERT ⇔ V:INVERT ⇔ H&V:INVERT ↓ If the Transition Detector is TURN ON and MIRROR status is changed, Transition Detector Alarm (151) will be displayed when projector is restarted after the power switch is turned off.
VOLUME	Using the ▲/▼ buttons adjusts the volume. High ⇔ Low
SPEAKER	Using the ▲/▼ buttons turns on/off the built-in speaker. TURN ON ⇔ TURN OFF When TURN OFF is selected, the built-in speaker does not work.

SETUP menu (continued)

Item	Description
AUDIO	 Allocates the audio ports. (1) Choose a picture input port using the ▲/▼ buttons. QUIT ⇔ COMPUTER (IN)1 ⇔ COMPUTER (IN)2 ↓ VIDE0 ⇔ S-VIDE0 ⇔ COMPONENT ⇔ MIU ⇔ HDMI (2) Select the audio port to be interlocked with the input port using the ◄/▶ buttons. [COMPUTER1, COMPUTER2, COMPONENT, S-VIDEO, VIDEO] 1 ⇔ 2 ⇔ 3 ⇔ ¥ [MIU] 1 ⇔ 2 ⇔ 3 ⇔ ¥ [MIU] 1 ⇔ 2 ⇔ 3 ⇔ ¥ (MIU] (MI
HDMI AUDIO	The HDMI AUDIO is set to 1 as default. In case the HDMI audio does not work well, try 2. 1 ⇔ 2

SCREEN menu

From the SCREEN menu, items shown in the table below can be performed.

Select an item using the \blacktriangle/\lor cursor buttons, and press the \blacktriangleright cursor button or ENTER button to execute the item. Then perform it according to the following table.

MENU [COMPUTER 1]		:SELECT
PICTURE	LANGUAGE (ENGLISH
IMAGE	MENU POSITION	-
INPUT	BLANK	BLACK
SETUP	START UP	ORIGINAL
SCREEN	MyScreen	
OPTION	MyScreen Lock	TURN OFF
MIU	MESSAGE	TURN ON
C.C.	SOURCE NAME	
EASY MENU		

Item		Description
LANGUAGE	ENGLISH ⇔ FRAN TÜRKÇE POLSKI SUOMI	ns switches the OSD (On Screen Display) language. NÇAIS ⇔ DEUTSCH ⇔ ESPAÑOL ⇔ ITALIANO NORSK NEDERLANDS PORTUGUÊS ISKA ⇔ 한글 ⇔ 繁體中文 ⇔ 简体中文 ⇔ 日本語
MENU POSITION	Using the $\blacktriangle/\bigtriangledown/\checkmark/$ buttons adjusts the menu position. To quit the operation, press MENU button on the remote control or keep no operation for about 10 seconds.	
	The BLANK screer (1222). It is display	tons switches the mode for the BLANK screen. a is a screen for the temporarily blanking feature ed by pressing BLANK button. RIGINAL ⇔ BLUE ⇔ WHITE ⇔ BLACK
BLANK	MyScreen	Feature Screen can be registered by the MyScreen item ((4 40).
	ORIGINAL	Screen preset as the standard screen.
	BLUE, WHITE, BLACK	Plain screens in each color.
	screen will change	g as an afterimage, the MyScreen or ORIGINAL to the plain black screen after several minutes.

SCREEN menu (continued)

Item	Description	
	The start-up screen i unsuitable signal is c	ons switches the mode for the start-up screen. s a screen displayed when no signal or an letected. GINAL ⇔ TURN OFF
		Feature
	MyScreen	Screen can be registered by the MyScreen item (140).
START UP	ORIGINAL	Screen preset as the standard screen.
	TURN OFF	Plain black screen.
	 To avoid remaining as an afterimage, the MyScreen or ORIGINAL screen will change to the BLANK screen (138) after several minutes. If also the BLANK screen is the MyScreen or ORIGINAL, the plain black screen is instead used. When the TURN ON is selected to the MyScreen PASSWORD of SECURITY item in OPTION menu (148), the START UP is fixed to MyScreen. 	

SCREEN menu (continued)

Item	Description
MyScreen	 This item allows you to capture an image for use as a MyScreen image which can be used as the BLANK screen and START UP screen. Display the image you want to capture before executing the following procedure. 1. Selecting this item displays a dialog titled "MyScreen". It will ask you if you start capturing an image from the current screen. Please wait for the target image to be displayed, and press the ENTER button when the image is displayed. The image will freeze and the frame for capturing will appear. To stop performing, press the RESET or ESC button. 2. Using the ▲/▼/ ◄/► buttons adjusts the frame position. Please move the frame to the position of the image which you want to use. The frame may not be able to be moved for some input signals. To start registration, press the RESET or ESC button. Registration takes several minutes. When the registration is completed, the registered screen and the following message are displayed for several seconds: "MyScreen registration is finished." If the registration failed, the following message is displayed: "A capturing error has occurred. Please try again." This function cannot be selected when the TURN ON is selected to the MyScreen PASSWORD of SECURITY item in OPTION menu (148).
MyScreen Lock	 Using the ▲/▼ buttons turns on/off the MyScreen lock function. TURN ON ⇔ TURN OFF When the TURN ON is selected, the MyScreen item is locked. Use this function for protecting the current MyScreen. This function cannot be selected when TURN ON is selected to the MyScreen PASSWORD of SECURITY item in OPTION menu (¹⁴⁸).

SCREEN menu (continued)

Item	Description	
	Using the ▲/▼ buttons turns on/off the message function. TURN ON ⇔ TURN OFF	
MESSAGE	When the TURN ON is selected, the following message function works. "AUTO IN PROGRESS" while automatically adjusting "NO INPUT IS DETECTED" "SYNC IS OUT OF RANGE" "Searching" while searching for the input "Detecting" while searching for the input "Detecting" while an input signal is detected The indication of the input signal displayed by changing The indication of the aspect ratio displayed by changing The indication of the PICTURE MODE displayed by changing The indication of the MY MEMORY displayed by changing The indication of "FREEZE" and "II" while the projector is in the FREEZE mode. If the projector goes into the FREEZE mode while the TURN OFF is selected, the picture on screen is frozen without any messages, which is not a malfunction. (
SOURCE NAME	Each input port for this projector can have a name applied to it. (1) Use the ▲/▼ buttons on the SCREEN menu to select SOURCE NAME and press the ▶ button. The SOURCE NAME menu will be displayed. (2) Use the ▲/▼ buttons on the SOURCE NAME menu to select the port to be named and press the ▶ button. Right side of the menu is blank until a name is specified. The SOURCE NAME dialog will be displayed. (3) The current name will be displayed on the first line. Use the ▲/▼/◄/▶ buttons and the ENTER or INPUT button to select and enter characters. The RESET button can be used to erase 1 character at a time. Also if you move the cursor to DELETE or ALL CLEAR on screen and push the ENTER or INPUT button, 1 character or all characters will be erased. The name can be a maximum of 16 characters. (4) To change an already inserted character, press the (▲) button to move the cursor to the first line, and use the ◄/▶ buttons to move the cursor on the character to be changed. After pressing the ENTER or INPUT button, the character is selected. Then, follow the same procedure as described at the item (3) above. (5) To finish entering text, move the cursor to the SAVE on screen and press the ENTER or INPUT button. To revert to the previous name without saving changes, move the cursor to the CANCEL on screen and press the ENTER or INPUT button.	



OPTION menu

From the OPTION menu, items shown in the table below can be performed.

Select an item using the \blacktriangle/\lor cursor buttons, and press the \blacktriangleright cursor button or ENTER button to execute the item, except for the items LAMP TIME and FILTER TIME. Then perform it according to the following table.

MENU [COMPUT	ER 1]	:SELECT
PICTURE	AUTO SEARCH	TURN ON
IMAGE	AUTO KEYSTON	E 🔼 TURN ON
INPUT	AUTO ON	TURN ON
SETUP	AUTO OFF	Omin
SCREEN	LAMP TIME	1234h
OPTION	FILTER TIME	123h
MIU	MY BUTTON	
C.C.	SERVICE	
EASY MENU	SECURITY	

Item	Description
AUTO SEARCH	Using the ▲/▼ buttons turns on/off the automatic signal search function. TURN ON ⇔ TURN OFF When the TURN ON is selected, detecting no signal automatically cycles through input ports in the following order. The search is started from the current port. Then when an input is found, the projector will stop searching and display the image. COMPUTER IN1 ⇔ COMPUTER IN2 ⇔ HDMI VIDEO ⇔ S-VIDEO ⇔ COMPONENT ⇔ MIU ↔
AUTO KEYSTONE 🔼	 Using the ▲/▼ buttons turns on/off the automatic keystone function. TURN ON ⇔ TURN OFF TURN ON : Automatic keystone distortion correction will be executed whenever changing the slant of the projector. TURN OFF : This function is disabled. Please execute the AUTO KEYSTONE ⊡ EXECUTE in the SETUP Menu for automatic keystone distortion correction. When the projector is suspended from the ceiling this feature will not function properly so select the TURN OFF. This function will be unavailable when the Transition Detector is on (15).
AUTO ON	 Using the ▲/▼ buttons turns on/off the AUTO ON function. TURN ON ⇔ TURN OFF When set to the TURN ON, the lamp in projector will be automatically turned on without the usual procedure (□16), only when the projector is supplied with the power after the power was cut while the lamp was on. This function does not work as long as the power has been supplied to the projector while the lamp is off. After turning the lamp on by the AUTO ON function, if neither input nor operation is detected for about 30 minutes, the projector is turned off, even though the AUTO OFF function (□43) is disabled.

ltem	Description
	Using the ▲/▼ buttons adjusts the time to count down to automatically turn the projector off. Long (max. 99 minutes) ⇔ Short (min. 0 minute = DISABLE)
	AUTO OFF ENABLE 1min Disable Omin
AUTO OFF	When the time is set to 0, the projector is not turned off automatically. When the time is set to 1 to 99, and when the passed time with no- signal or an unsuitable signal reaches at the set time, the projector lamp will be turned off. If one of the projector's buttons or the remote control buttons is pressed or one of the commands (except get commands) is transmitted to the CONTROL port during the corresponding time, projector will not be turned off. Please refer to the section "Turning off the power" (116).
LAMP TIME	The lamp time is the usage time of the lamp, counted after the last resetting. It is shown in the OPTION menu. Pressing RESET button or the ▶ button displays a dialog. To reset the lamp time, select RESET using the ▲ button. RESET ⇔ CANCEL • Please reset the lamp time only when you have replaced the lamp, for a suitable indication about the lamp.
	• For the lamp replacement, see the section "Lamp" (164). The filter time is the usage time of the air filter, counted after the last resetting. It is shown in the OPTION menu.
FILTER TIME	 Pressing the RESET button or the ▶ button displays a dialog. To reset the filter time, select the RESET using the ▲ button. RESET ⇔ CANCEL Please reset the filter time only when you have cleaned or replaced the air filter, for a suitable indication about the air filter. For the air filter cleaning, see the section "Air filter" (166).

Item	Description
MY BUTTON	This item is to assign one of the following functions to MY BUTTON 1 and 2 on the remote control (1 6). Choose 1 or 2 on the MY BUTTON menu using the ◄/► button first. Then using the ▲/▼ buttons sets one of the following functions to the chosen button. • COMPUTER1: Sets port to COMPUTER IN1. • COMPUTER2: Sets port to COMPUTER IN2. • HDMI: Sets port to HDMI. • MIU: Sets port to HDMI. • S-VIDEO: Sets port to COMPONENT(Y, Cb/Pb, Cr/Pr) • S-VIDEO: Sets port to VIDEO. • VIDEO: Sets port to VIDEO. • VIDEO: Sets port to VIDEO. • INFORMATION: (1 62) or nothing. The displayed dialog is switched as below every time the MY BUTTON is pushed. When an input signal is found: INPUT -INFORMATION- (1 62) or nothing. The displayed dialog is switched as below every time the MY BUTTON is pushed. When an input signal is not found: MIU -INFORMATION- ⇔ OFF • AUTO KEYSTONE [2] : Performs automatic keystone distortion correction (1 35). • MY MEMORY: Loads one of adjustment data stored (1 29). When more than one data are saved, the adjustment changes every time the MY BUTTON is pushed. When no data is saved in memory, the dialog "No saved data" appears. If you want to keep the current adjustment, please press the ◄ button to quit. Otherwise loading a data will lose the current adjusted condition. • PICTURE MODE: Changes the PICTURE MODE (1 25). • FILTER RESET: Displays the filter time reset confirmation dialogue (1 43). • VOLUME-: Set the volume up. • VOLUME-: Set sport to MIU and displays an image on the LIVE MODE. While using the LIVE MODE, the LIVE MODE SETTING menu is displayed. • THUMBNAIL : Sets port to MIU and displays the THEUMBNAIL screen. • SLIDE SHOW : Sets port to MIU and displays the THEUMENAIL screen. • SLIDE SHOW : Sets port to MIU and displays the THEUMENAIL screen. • SLIDE SHOW : Sets port to MIU and displays the THEUMENAIL screen. • S
SERVICE	Selecting this item displays the SERVICE menu. Select an item using the ▲/▼ buttons, and press the ► button or the ENTER button to execute the item. FAN SPEED ⇔ AUTO ADJUST ⇔ GHOST ⇔ FILTER MESSAGE ⇔ KEY LOCK ↓ FACTORY RESET ⇔ I NFORMATION ⇔ REMOTE FREQ. ↓

Item	Description	
	FAN SPEED Using the ▲/▼ buttons the rotation speed of the cooling fans. The HIGH is the mode for use at highlands etc. Note that the projector is noisier when the HIGH is selected. HIGH ⇔ NORMAL	
	 AUTO ADJUST Using the ▲/▼ buttons to select one of the mode. When the DISABLE is selected, the automatic adjustment feature is disabled. FINE ⇔ FAST ⇔ DISABLE FINE: Finer tuning including H.SIZE adjustment. FAST: Faster tuning, setting H.SIZE to prearranged data for the input signal. Depending on conditions, such as input image, signal cable to the projector, environment around the projector, etc., the automatic adjustment may not work correctly. In such a case, please choose DISABLE to disable the automatic adjustment, and make 	
SERVICE (continued)	 adjustment manually. GHOST 1. Select a color element of ghost using the buttons. 2. Adjust the selected element using the ▲/▼ buttons to disappear ghost. 	
	FILTER MESSAGE Use the ▲/▼ button to set the timer for the interval to show the message for cleaning up the air filter. 50h ⇔ 100h ⇔ 200h ⇔ 300h ⇔ 400h ⇔ 500h TURN OFF ⇔ 800h ⇔ 700h ⇔ 600h ⇔ After choosing an item except TURN OFF, the message "REMINDER *** HRS PASSED AFTER THE LAST FILTER CHECK" will appear after the timer reaches the interval time set by this feature (170). When the TURN OFF is chosen, the message will not appear. Utilize this feature to keep the air filter clean, setting the suitable time according to your environment of this projector. • Please check and clean the air filter periodically, even if there is no message. If the air filter becomes to be blocked by dust or others, the internal temperature will rise, which could cause malfunction, or reduce the lifetime of the projector. • Please be careful with the operating environment of the projector and the condition of the air filter.	



ltem	Description
	KEY LOCK Using the ▲/▼ buttons turns on/off the key lock feature. When TURN ON is selected, the buttons on the projector except the STANDBY/ON button are locked. TURN ON ⇔ TURN OFF
	• Please use to avoid a mischief and touching accidentally. This function does not have any effect on the remote control.
SERVICE (continued)	REMOTE FREQ. Use the ▲/▼ button to change the projector's remote sensor setting. 1:NORMAL ⇔ 2:HIGH Items with a checkmark are on. The factory default setting is for both 1:NORMAL and 2: HIGH to be on. If the remote control does not function correctly set this to either only 1 or only 2 (115). Neither can be turned off at the same time.
	INFORMATION Selecting this item displays a dialog titled "INPUT -INFORMATION-". It shows the information about the current input. INPUT -INFORMATION-". COMPUTER 1 COMPUTER 1 COMPONENT 1024/788 Goldz FRAME LOCK
	 The "FRAME LOCK" message on the dialog means the frame lock function is working (¹³³). This item can't be selected for no signal and sync out.
	FACTORY RESET Selecting RESET using the button ▲ performs this function. By this function, all the items in all of menus will collectively return to the initial setting. Note that the items LAMP TIME, FILTER TIME, LANGUAGE, SECURITY and MIU settings are not reset. RESET ⇔ CANCEL

Item	Description		
	This projector is equipped with security functions. User registration is required before using the security functions. Please contact your local dealer.		
	1. Using Security Features		
	1.1 Inputting the PASSWORD SECURITY		
	1.1-1 Use the ▲/▼ buttons on the OPTION menu to select SECURITY and press the button. The ENTER PASSWORD box will be displayed. The factory default PASSWORD is 8471 . This PASSWORD can be changed (1.2 Changing the PASSWORD (Default).		
	 It is strongly recommended the factory default PASSWORD to be changed as soon as possible. 		
SECURITY	1.1-2 Use the ▲/▼/◀/▶ buttons to enter the registered PASSWORD. Move the cursor to the right side of the ENTER PASSWORD box and press the ▶ button to display the SECURITY menu. If an incorrect PASSWORD is input the ENTER PASSWORD box will be displayed again. If incorrect PASSWORD is input 3 times the projector will turn off. Afterwards the projector will turn off every time an incorrect PASSWORD is input.		
	1.2 Changing the PASSWORD		
	1.2-1 Use the ▲/▼ buttons on the SECURITY menu to select SECURITY PASSWORD CHANGE and press the ► button to display the ENTER NEW PASSWORD box.		
	1.2-2 Use the ▲/▼/◀/► buttons to enter the new PASSWORD.		
	1.2-3 Move the cursor to the right side of the ENTER NEW PASSWORD box and press the ► button to display the NEW PASSWORD AGAIN box, enter the same PASSWORD again.		
	1.2-4 Move the cursor to the right side of the NEW PASSWORD AGAIN box and press the ► button and the NOTE NEW PASSWORD box will be displayed for about 20 seconds, please make note of the PASSWORD during this time. Pressing the ENTER button will close the NOTE NEW PASSWORD		
	box. • Please do not forget your PASSWORD.		

Item	Description		
	 1.3 If you have forgotten your PASSWORD 1.3-1 Follow the procedure in 1.1-1 to display the ENTER PASSWORD box. 		
	 1.3-2 While the ENTER PASSWORD box is displayed, press and hold the RESET button for about 3 seconds or press and hold the INPUT and ▶ buttons on the projector for about 3 seconds. The 10-digit Inquiring Code will be displayed. If there is no key input for about 55 seconds while the Inquiring Code is displayed the menu will close. If necessary repeat the process from 1.3-1. 1.3-3 Contact your dealer with the 10-digit Inquiring Code. Your PASSWORD 		
	will be sent after your user registration information is confirmed.		
	2. Using the MyScreen PASSWORD Function The MyScreen PASSWORD function can be used to prohibit access to the MyScreen function and prevent the currently registered MyScreen image from being overwritten.		
SECURITY	2.1 Turning on the MyScreen PASSWORD Function		
(continued)	2.1-1 Use the ▲/▼ buttons on the SECURITY menu to select MyScreen PASSWORD and press the ► button to display the MyScreen PASSWORD on/off menu.		
	2.2 Setting the PASSWORD		
	2.2-1 Display the MyScreen PASSWORD on/off menu using the procedure in 2.1-1.		
	2.2-2 Use the ▲/▼ buttons on the MyScreen PASSWORD on/off menu to select TURN ON. The ENTER PASSWORD box (small) will be displayed.		
	2.2-3 Use the ▲/▼/◀/► buttons to enter the PASSWORD. Move the cursor to the right side of the ENTER PASSWORD box (small) and press the ► button to display the PASSWORD AGAIN box, enter the same PASSWORD again.		

Item	Description		
	 2.2-4 Move the cursor to the right side of the PASSWORD AGAIN box and press the button to display the PASSWORD for about 20 seconds, please make note of the PASSWORD during this time. Pressing the ENTER button will return to MyScreen PASSWORD on/off menu. When a PASSWORD on/off menu. When a PASSWORD is set for MyScreen: The MyScreen registration function (and menu) will be unavailable. The START UP setting will be locked on MyScreen (and the menu will be unavailable). Turning the MyScreen PASSWORD off will allow normal operation of these functions. Please do not forget your MyScreen PASSWORD. 		
	2.3 Turning the PASSWORD off		
	2.3-1 Follow the procedure in 2.1-1 to display the MyScreen PASSWORD on/off menu.		
SECURITY (continued)	 2.3-2 Select TURN OFF to display the ENTER PASSWORD box (large). Enter the registered PASSWORD and the screen will return to the MyScreen on/off menu. If an incorrect PASSWORD is input the menu will close. If necessary repeat the process from 2.3-1. 		
	2.4 If you have forgotten your PASSWORD		
	2.4-1 Follow the procedure in 2.1-1 to display the MyScreen PASSWORD on/off menu.		
	2.4-2 Select TURN OFF to display the ENTER PASSWORD box (large). The 10-digit Inquiring Code will be displayed inside the box.		
	2.4-3 Contact your dealer with the 10-digit Inquiring Code. Your PASSWORD will be sent after your user registration information is confirmed.		
	3. Using the PIN LOCK Function PIN LOCK is a function which prevents the projector from being used unless a registered Code is input.		
	3.1 Registering the PIN Code		
	3.1-1 Use the ▲/▼ buttons on the SECURITY menu to select PIN LOCK and press the ► button or the ENTER button to display the PIN LOCK on/off menu.		

ltem	Description		
	3.1-2 Use the ▲/▼ buttons on the PIN LOCK on/off menu to select TURN ON and the PIN BOX will be displayed.		
SECURITY (continued)	 3.1-3 Input a 4 part PIN Code using the ▲, ▼, Image: A pin Code again box will appear. Reenter the same PIN Code. This will complete the PIN Code registration. If there is no key input for about 55 seconds while the PIN BOX or the PIN Code again box are displayed the menu will close. If necessary repeat the process from 3.1-1. Afterwards, anytime the projector is restarted after AC power is turned off the PIN BOX will be displayed. Enter the registered PIN Code. If an incorrect PIN Code is input the PIN BOX will be displayed. Enter the registered PIN Code. If an incorrect PIN Code is input the PIN BOX will be displayed again. If an incorrect PIN Code is input 3 times the projector will turn off. Afterwards the projector will also turn off if there is no key input for about 5 minutes while the PIN BOX is displayed. This function will activate only when the projector is started after AC power is turned off. 		
	3.2 Turning Off the PIN LOCK Function		
	 3.2-1 Follow the procedure in 3.1-1 to display the PIN LOCK on/off menu. Use the ▲/▼ buttons to select TURN OFF and the PIN BOX will be displayed. Enter the registered PIN Code to turn the PIN LOCK function off. If an incorrect PASSWORD is input 3 times, the menu will close. 		
	3.3 If you have forgotten your PIN Code		
	 3.3-1 While the PIN BOX is displayed, press and hold the RESET button for 3 seconds or press and hold the INPUT and ► buttons for 3 seconds. The 10-digit Inquiring Code will be displayed. If it passes for about 5 minutes after the PIN BOX is displayed the projector will turn off. 		
(continued on next p	3.3-2 Contact your dealer with the 10-digit Inquiring Code. Your PASSWORD will be sent after your user registration information is confirmed.		

Item	Description		
	4. Using the Transition Detector Function		
	 While the Transition Detector function is ON, when p to supply to the projector, it might react as below. Transition Detector alarm shown below might apper projector has been moved or re-installed. Transition Detector alarm might appear on screen, has been changed. Keystone adjustment feature has been prohibited a Detector function is ON. 	ear on screen, if the , if the MIRROR setting	
	4.1 Turning On the Transition Detector Fu	unction	
	 4.1-1 Use the ▲/▼ buttons on the SECURITY menu to select TRANSITION DETECTOR and press the ▶ or the ENTER button to display the TRANSITION DETECTOR on/off menu. Select TURN ON and the current angle and mirror setting will be recorded. This feature may not function properly if the proj position when TURN ON is selected. 	TRANSITION DETECTOR TURN ON TURN OFF	
SECURITY (continued)	4.1-2 If this function is set to TURN ON when the vertical angle of the projector or mirror setting at which the projector is turned on is different than the previously recorded the Transition Detector alarm will be displayed and the projector will not display the input signal.	< <transition detector="" on="">> The projector has been transferred from previously installed position. If you wish to have a square image on screen again, disable Transition Detector on Menu.</transition>	
	Set the Transition Detector off in the SECURITY is signal. If the Transition Detector alarm is displayed for at will turn off. This function will activate only when t after turning off the AC power.	pout 5 minutes the lamp	
	4.2 Setting the Transition Detector PASS	WORD	
	4.2-1 Use the ▲/▼ buttons on the SECURITY men DETECTOR and press the ▶ or the ENTER b TRANSITION DETECTOR on/off menu.		
	4.2-2 Use the ▲/▼ buttons on the TRANSITION DETECTOR on/off menu to select TURN ON. The ENTER PASSWORD box (small) will be displayed.	TRANSITION DETECTOR ENTER PASSWORD	
	4.2-3 Use the ▲/▼/ buttons to enter a PASSWORD. Move the cursor to the right side of the ENTER PASSWORD box (small) and press the button to display the PASSWORD AGAIN box, enter the same PASSWORD again.</td <td>TRANSITION DETECTOR PASSWORD AGAIN</td>	TRANSITION DETECTOR PASSWORD AGAIN	



Item	Description		
	 4.2-4 Move the cursor to the right side of the PASSWORD AGAIN box and press the button to display the PASSWORD for about 20 seconds, please make note of the PASSWORD during this time. Pressing the ENTER button will return to the TRANSITION DETECTOR on/off menu. Please do not forget your Transition Detector PASSWORD. 		
	 4.3 Setting the Transition Detector off 4.3-1 Follow the procedure in 4.1-1 to display the TRANSITION DETECTOR on/off menu. 		
SECURITY (continued)	4.3-2 Select TURN OFF to display the ENTER PASSWORD box (large). Enter the registered PASSWORD and the screen will return to the TRANSITION DETECTOR on/off menu. If an incorrect PASSWORD is input the menu will close. If necessary repeat the process from 4.3-1.		
	4.4 If you have forgotten your PASSWORD		
	4.4-1 Follow the procedure in 4.1-1 to display the TRANSITION DETECTOR on/off menu.		
	4.4-2 Select TURN OFF to display the ENTER PASSWORD box (large). The 10-digit Inquiring Code will be displayed inside the box.		
	4.4-3 Contact your dealer with the 10-digit Inquiring Code. Your PASSWORD will be sent after your user registration information is confirmed.		

MIU menu

The MIU (Multi Information processing Unit) is a function to support the Network features and PC-LESS Presentation. Remember that incorrect network settings on this projector may cause trouble on the network. Be sure to consult with your network administrator before connecting to an existing access point on your network.

MENU [COMPUTER 1] (D:SELECT		
PICTURE	LIVE MODE	
IMAGE	LIVE MODE SETTING	
INPUT	PC-LESS PRESENTATION	
SETUP	SETUP	
SCREEN	PROJECTOR NAME	
OPTION	e-SH0T	
MIU	INFORMATION	
C.C.	SERVICE	
EASY MENU		

Select "MIU" from the main menu to access the following functions.

Select an item using the \blacktriangle/∇ cursor buttons on the projector or remote control, and press the \blacktriangleright cursor button on the projector or remote control, or ENTER button on the remote control to execute the item. Then perform it according to the following table.

See the User's Manual - Network Guide for details of MIU operation.

NOTE • The factory default setting for DHCP is OFF. If your network has DHCP enabled, and needs to set IP ADDRESS, SUBNET MASK and DEFAULT GATEWAY automatically, please set DHCP to ON. (Network Settings of the User's Manual - Network Guide)

• If you are not utilizing SNTP (Date/Time Settings of the User's Manual

- Network Guide), then you must set the DATE AND TIME (157) during the initial installation.

Item	Description		
LIVE MODE	Selecting this item sets the projector onto the "Live Mode". On the "Live Mode", the projector displays the images from the PC via Network, supported by "MIU Live Viewer". (Live Mode of the User's Manual - Network Guide) In the Live Mode, the message "Waiting for connection" will be displayed until the "MIU Live Viewer" start to send computer screen image.		
LIVE MODE SETTING	Selecting this item displays the LIVE MODE SETTING menu. Use the ▲/▼ buttons to select an item, and the ► or ENTER button to perform the item.		



Item	Description		
	QUIT PRESENTER MODE	The Presenter Mode that is set in the Live Viewer 3 software installed into your PC can be turned to off. A message, QUIT PRESENTER MODE, will be displayed in about 3 seconds when the function is performed. The function is available only when the Presenter Mode is set to on in the Live Viewer 3 software. The current setting of the Presenter Mode is shown in the menu. • The Presenter mode is a function that allows the projector to display an image sent by 1 PC only, even though the MIU feature on this projector support Multi PC mode. • If the projector is required to display an image sent by other PC, execute the QUIT PRESENTER MODE function. • See the User's Manual – Network Guide for details. (
LIVE MODE SETTING (continued)	MULTI PC MODE	The projector supports the Single PC mode that displays an image on full screen sent by 1 PC, and the Multi PC mode that divides the screen into 4 zone and displays images in each zone sent by up to 4 PCs. The MULTI PC MODE function switches these modes. SINGLE Use the ▲/▼ buttons to select an item, and the ENTER or INPUT button to perform the item. The mode will be switched from the Multi PC mode to the Single PC mode and the quarter screen identified in the menu will be displayed on full screen. MULTI Use the ENTER or INPUT button to perform the item. The mode will be switched to the Multi PC mode and the screen will be divided to 4 zones. • If the Presenter Mode is set to on in the PC whose image is currently displayed on screen, a message, QUIT PRESENTER MODE, will be displayed in about 3 seconds when the function is performed. • The function is available when there is any PC connected to the projector in the Multi PC mode set in the Live Viewer 3 software.	

Item	Description	
LIVE MODE SETTING (continued)	DISPLAY USER NAME	Selecting this item displays the Display User Name defined in the Live View3 software in the PC whose image is on screen.
		SINGLE PC mode The Display User Name will be shown in the DISPLAY USER NAME box.
		Examples Display User name Shown in the DISPLAY USER NAME box PC_NAME0001 PC_NAME0001 (remained as default) Unnamed (blank space) (prohibited showing) (Anonymous)
		If there is no PC in the Single PC mode connected to the projector, the DISPLAY USER NAME box is shown as right.
		MULTI PC mode The Display User Names will be shown in the DISPLAY USER NAME box.
		• See the User's Manual – Network Guide for details of the Display User Name setting. (
PC-LESS	Selecting this item displays the PC-LESS PRESENTATION menu. Using the menu is able to make the projector display the images stored in an SD memory card or a USB memory, and realizes a presentation without a PC. Use the ▲/▼/◀/► buttons to select an item, and the ► or ENTER button to perform the item. • While displaying the image, to press the MENU button displays the PC-LESS PRESENTATION menu.	
PRESENTATION	THUMBNAIL	Use the ▲/▼/◀/► buttons to select an image, and press the ENTER or INPUT button to display the image.
	SLIDE SHOW	Slide show will start when you press the ENTER or ► button.



Item		Description		
	DIRECTORY	Use the ▲/▼ buttons to select an image or a folder, and press the ENTER button to display the image or turn into the THUMBNAIL. To open or close the folder, press the ►/◀ buttons.		
DO 1 500	DISPLAY SIZE	Use the ▲/▼ buttons to set the display size.		
PC-LESS PRESENTATION (continued)	KEY CONFIG.	Use the ▲/▼ buttons to select key configuration from the 2 patterns.		
	REMOVE MEDIA	Use the ▲/▼ buttons to select a remove mode, and then the ENTER or ► button is pressed so the menu will appear.		
	• Also these items can be set with Web Remote Control (Refer to Network Guide) except REMOVE MEDIA.			
menu. Use the ▲/▼ buttons to select an item, and the ▶ or ENTER button on the remote control to perform the item.		V buttons to select an item, and NTER button on the remote control the item.		
SETUP	DHCP (Dynamic Host Configuration Protocol)	Use the ▲/▼ buttons to turn DHCP on/off. ON ⇔ OFF Select OFF when the network does not have DHCP enabled. • When the "DHCP" setting changes to "ON", it takes a little time to obtain IP address from DHCP server. • Auto IP function will be assigned an IP address if the projector could not obtain an IP address from server even if DHCP is "ON".		

Item		Description		
SETUP (continued)	IP ADDRESS	Use the ▲/▼/◀/► buttons to enter the IP ADDRESS. This function can only be used when DHCP is set to OFF.		
		 The IP ADDRESS is the number that identifies this projector on the network. You cannot have two devices with the same IP ADDRESS on the same network. The IP ADDRESS "0.0.0.0" is prohibited. 		
	SUBNET MASK	Use the ▲/▼/◀/► buttons to enter the same SUBNET MASK used by your PC. This function can only be used when DHCP is set to OFF.		
	DEFAULT GATEWAY	The SUBNET MASK "0.0.0.0" is prohibited. Use the ▲/▼/◀/▶ buttons to enter the DEFAULT GATEWAY (a node on a computer network that serves as an access point to another network) address. This function can only be used when DHCP is set to OFF.		
	DNS SERVER	Use the ▲/▼/◀/▶ buttons to input the DNS server address. The DNS server is a system to control domain names and IP addresses on the Network.		
	TIME DIFFERENCE	Use the ▲/▼ buttons to enter the TIME DIFFERENCE. Set the same TIME DIFFERENCE as the one set on your PC. If unsure, consult your IT manager. Use the ◀ button to return to the menu after setting the TIME DIFFERENCE.		
	DATE AND TIME	Use the ▲/▼/◀/► buttons to enter the Year (last two digits), Month, Date, Hour and Minute. • The projector will override this setting and retrieve DATE AND TIME information from the Time server when SNTP is enabled. (Date/Time Settings of the User's Manual - Network Guide)		



Item	Description		
	MODE	Use the ▲/▼ buttons to select the mode of the network communication system. Select it according to the setting of your PC.	
		ADHOC ⇔ INFRASTRUCTURE	
	СН	Use the ▲/▼ buttons to select the channel of the wireless LAN while using it. Select it according to the setting of your PC. The channels 1 to 11 are available. • The available channels would be various depending on a country. In addition, wireless network card might be required due to the standard.	
	ENCRYPTION	Use the ▲/▼ buttons to select the encryption method to be used. WPA2-PSK(AES) WPA2-PSK(AES) WPA2-PSK(AES) WPA2-PSK(AES) WPA2-PSK(AES) WPA2-PSK(AES) WPA2-PSK(AES) WPA2-PSK(AES) WPA2-PSK(AES)	
SETUP (continued)	SSID	Use the ▲/▼ buttons to select the SSID to display the SSID menu. SSID #1 DEFAULT : wireless #2 DEFAULT : WLANprojector 1 #3 DEFAULT : WLANprojector 2 #4 DEFAULT : WLANprojector 3 #5 CUSTOM D : 01234567890123456789012345678901 DEFAULT Pressing the ▶ or ENTER button when one of the DEFAULT (#1~#4) is selected. CUSTOM Press the ▶ or ENTER button when the # 5 CUSTOM is selected. The SSID #5 CUSTOM menu will be appeared. (1) The current SSID will be displayed on the first line. If not yet written, the line will be blank. Use the ▲/▼/◄/→ buttons and the ENTER or INPUT button to select and enter characters. The RESET button can be used to erase 1 character at a time. Also if you move the cursor to DELETE or ALL CLEAR on screen and push the ENTER or INPUT button, 1 character or all characters will be erased. The SSID can be input up to 32 characters.	

Item	Description		
SETUP (continued)	SSID (continued)	 (2) To change an already inserted character, press the ▲/▼ button to move the cursor to one of the first 2 lines, and use the ◄ /▶ buttons to move the cursor to be changed. After pressing the ENTER or INPUT button, the character is selected. Then, follow the same procedure as described at the item (1) above (3) To finish entering text, move the cursor to the SAVE on screen and press the ENTER or INPUT button. To revert to the previous SSID without saving changes, move the cursor to the CANCEL on screen and press the ENTER or INPUT button. To revert to the previous SSID without saving changes, move the cursor to the CANCEL on screen and press the ENTER or INPUT button. To revert to the previous SSID without saving changes, move the cursor to the CANCEL on screen and press the ENTER or INPUT button. 	
	SPEED	Use the ▲/▼ buttons to select the transfer rate. (M : Mbps : Megabits per second) AUTO⇔54M⇔48M⇔36M⇔24M⇔18M ↑ 1M⇔2M⇔5.5M⇔6M⇔9M⇔11M⇔12M • The AUTO mode automatically selects the optimum rate. • Transfer rates may change due to the network situation.	
	NETWORK MODE	Use the ▲/▼ buttons to select the network mode. WIRELESS ⇔ WIRED • The network mode will be initialized whenever the power is turned on with the power switch. • The WIRELESS will be enabled when the wireless network card is inserted. • The WIRED will be enabled when the wireless network card is not inserted.	

Item	Description		
PROJECTOR NAME	 (1) Use the ▲/▼ buttons on the MIU men PROJECTOR NAME menu and press PROJECTOR NAME dialog will be dis (2) The current PROJECTOR NAME will be displayed on the first 3 lines. If not yet written, the lines will be blank. Use the ▲/▼/◀/► buttons and the ENTER or INPUT button to select and enter characters. The RESET button can be used to erase 1 character at a time. Also if you move the cursor to DELETE or ALL CLEAR on screen and push the ENTER or INPUT button, 1 character or all characters will be erased. The PROJECTOR NAME can be input up to 64. (3) To change an already inserted 	the 🕨 button. The	
	(3) To character, press the ▲/▼ button to move the cursor to one of the first 3 lines, and use the ◀/► buttons to move the cursor on the character to be changed. After pressing the ENTER or INPUT button, the character is selected. Then, follow the same procedure as described at the item (2) above.	PROJECTOR UNIE DESKOVE P roject@r Project@r A B C D E F G H i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z a b c d e f a h i J K L W N O P O R S T U V X Y Z b c d e f a h i J K L W N O P O R S T U V X Y Z b c d e f a h i J K L W N O P O R S T U V X Y Z b c d e f a h i J K L W N O P O R S T U V X Y Z b c d e f a h i J K L W N O P O R S T U V X Y Z c d e f a h i J K L W N O P O R S T U V X Y Z c d e f a h i J K L W N O P O R S T U V X Y Z c d e f a h i J K L W N O P O R S T U V X Y Z c d e f a h i J K L W N O P O R S T U V X Y Z c d e f a h i J K L W N O P O R S T U V X Y Z c d e f a	
	(4) To finish entering text, move the cursor to the SAVE on screen and press the ENTER or INPUT button. To revert to the previous PROJECTOR NAME without saving changes, move the cursor to the CANCEL on screen and press the ENTER or INPUT button.	Projector Some Projector	

Item	Description
	Selecting this item displays the e-SHOT menu. Insert the SD memory card or USB memory into the projector before you use the e-SHOT function. (□61) The application software "PJTransfer" is required to store image(s) into the projector. Use the ▲/▼ buttons to select an item which is a still image by the e-SHOT (□ e-SHOT (Still Image Transfer) Display of the User' s Manual - Network Guide) and the ► or ENTER button to display the image. • The item without image stored cannot be selected. • The image names are each displayed in 16 characters or less.
e-SHOT	To switch the image displayed Use the ▲/▼ buttons. To return to the menu Press the ◀ or ESC button on the remote control.
	To erase the image displayed and its source file in the SD memory card or USB memory
	 (1) Press the RESET button on the remote control while displaying an image to display the e-SHOT - RESET menu. (2) Press the ENTER button on the remote control or the INPUT button on the projector to perform to erase. To stop erasing, press the ESC button on the remote control or the 4 button on the projector.

ltem	Description					
Item	Selecting this item displays the MIU-INFORMATION- dialog for confirming the network settings. MUU-INFORMATION PASSCODE: 1234-5678-9ABC PROJECTOR NAME: Projector PASSCODE: 1234-5678-9ABC IPADRESS 192.168.1.10 SUBNET MASK 255.255.255.0 DEFAULT GATEWAY 0.0.0.0 DNS SERVER 0.0.0.0 DAS SERVER 0.0.0.0 DATE AND TIME 2000/1/1 0.00 MODE ADHOC CH 11 MODE ADHOC CH 11 MAC ETHERNET 00-00-87-56-AC-DA MODE ADHOC CH 11 MAC WIRELESS 00-00-87-56-AC-DA MAC WIRELESS 00-00-10-02-00-62 • The PROJECTOR NAME is displayed. • Nothing (blank) is shown in the "PROJECTOR NAME" and "SSID" field until you setup those items. (158 , 59, 60) • When the voltage level of the battery for the built in clock decreases, the set time may become incorrect even though accurate date and time are input. Replace the battery suitably. (166) • MAC wireless will not be displayed when the NETWORK MODE is set to the WIRED even if the wireless network card is mounted. • IP ADDRESS, SUBNET MASK and DEFAULT GATEWAY indicate "0.0.0.0" in the following condition. (1) The NETWORK MODE is set to the WIRELESS and the wireless network card is					
	 server. Nothing (blank) is shown in the "CH", "SPEED" and "MAC WIRELESS" field in case of either no wireless network card is inserted or "WIRED" mode is selected at NETWORK MODE, or both. The actual performance and setting will be shown in the "CH" and 					
	"SPEED" field, instead of the setting value in the SETUP menu.					
	MIU RESTART Use the ▲ button to restart the network communication. The network communication will be cut off once and restarted.					
SERVICE	MIU RESTART EXECUTE CANCEL					
	EXECUTE ⇐ CANCEL • After selecting the EXECUTE, the MIU menu may not be					
	controlled approximately 20 seconds. • If DHCP is ON, IP address may be changed.					

C.C. (Closed Caption) menu

The closed caption setting can be changed through C.C. menu in the advance menu. Please select the item that you will change using \blacktriangle/∇ cursor buttons.

• The C.C. (Closed Caption) is the function that displays a transcript or dialog of the audio portion of a video, files or other presentation or other relevant sounds. It is required to have NTSC format video source supporting C.C. feature to utilize this function.

	– • •
Item	Description
	Select Closed Caption DISPLAY setting from following options using ▲/▼ buttons. TURN OFF ⇔ TURN ON ⇔ AUTO
DISPLAY	 TURN OFF: Closed Caption is OFF TURN ON: Closed Caption is ON AUTO: Closed Caption automatically displays when the volume is muted. The caption is not displayed when the OSD menu is active. The Closed Caption is the function to display the dialogue, narration, and / or sound effects of a television program or other video sources. The Closed Caption availability is depending upon broadcaster and/or content. The caption is only available if the video source is NTSC format and the video format selection is AUTO or NTSC on the INPUT menu. It may not work properly, depending on equipment or signal source. In this case, please turn off the Closed Caption.
MODE	Select Closed Caption MODE setting from following options using ▲/▼ buttons. CAPTIONS ⇔ TEXT CAPTIONS: Display Closed Caption TEXT: Display Text data, which is for additional information such as news reports or a TV program guide. The information covers the entire screen. Not all of the C.C. program has Text information.
CHANNEL	Select Closed Caption CHANNEL from following options using ▲/▼ buttons. 1 ⇔ 2 ⇔ 3 ⇔ 4 1: Channel 1, primary channel / language 2: Channel 2 3: Channel 3 4: Channel 4 The channel data may vary, depending on the content. Some channel might be used for secondary language or empty.

Maintenance

Replacing the lamp

A lamp has finite product life. Using the lamp for long periods of time could cause the pictures darker or the color tone poor. Note that each lamp has a different lifetime, and some may burst or burn out soon after you start using them. Preparation of a new lamp and early replacement are recommended. To prepare a new lamp, contact to your dealer and tell the lamp type number.

Type number : DT00841

Replacing the lamp

- Turn the projector off, and unplug the power cord.
- Allow the projector to cool for at least 45 minutes.
- Prepare a new lamp. If the projector is mounted on
- 2. Prepare a new ramp. If the projection a ceiling, or if the lamp has broken, also ask the dealer to replace the lamp.

In case of replacement by yourself, follow the following procedure.

- Loosen the screw (marked by arrow) of the lamp cover 3. Loosen the screw (marked b) survey, and then slide the lamp cover to the side to remove it.
- Loosen the 2 screws (marked by arrow) of the 4. Loosen the 2 solews (manage 2) in a lamp, and slowly pick up the lamp by the handles.
- Insert the new lamp, and retighten firmly the 5. Insert the new ramp, and reasonable in the 2 screws of the lamp that are loosened in the previous process to lock it in place.
- Slide the lamp cover back in place and firmly 6. Slide the lamp cover. fasten the screw of the lamp cover.
- Turn the projector on and reset the lamp time using
- 7. the LAMP TIME item in the OPTION menu.
 - (1) Press the MENU button to display a menu.
 - (2) Point at the Go to Advanced Menu ... in the menu using the ∇/\blacktriangle button, then press the \blacktriangleright button.
 - (3) Point at the OPTION in the left column of the menu using the ∇/A button, then press the \triangleright button.
 - (4) Point at the LAMP TIME using the V/▲ button, then press the ► button. A dialog will appear.
 - (5) Press the ▲ button to select RESET on the dialog. It performs resetting the lamp time.


Do not touch any inner space of the projector, while the lamp is taken out.

NOTE • Please reset the lamp time only when you have replaced the lamp, for a suitable indication about the lamp.





Handles



Replacing the lamp (continued)

Lamp warning

A HIGH TEMPERATURE

A HIGH PRESSURE

▲ WARNING ► The projector uses a high-pressure mercury glass lamp. The lamp can break with a loud bang, or burn out, if jolted or scratched, handled while hot, or worn over time. Note that each lamp has a different lifetime, and some may burst or burn out soon after you start using them. In addition, when the bulb bursts, it is possible for shards of glass to fly into the lamp housing, and for gas containing mercury to escape from the projector's vent holes.

► About disposal of a lamp: This product contains a mercury lamp; do not put it in a trash. Dispose of it in accordance with environmental laws.

• For lamp recycling, go to <u>www.lamprecycle.org</u> (in the US).

• For product disposal, contact your local government agency

or <u>www.eiae.org</u> (in the US) or <u>www.epsc.ca</u> (in Canada).

For more information, call your dealer.

Disconnect the plug from the power outlet	 If the lamp should break (it will make a loud bang when it does), unplug the power cord from the outlet, and make sure to request a replacement lamp from your local dealer. Note that shards of glass could damage the projector's internals, or cause injury during handling, so please do not try to clean the projector or replace the lamp yourself. If the lamp should break (it will make a loud bang when it does), ventilate the room well, and make sure not to breathe the gas that comes out of the projector vents, or get it in your eyes or mouth. Before replacing the lamp, turn the projector off and unplug the power cord, then wait at least 45 minutes for the lamp to cool sufficiently. Handling the lamp while hot can cause burns, as well as damaging the lamp.
\bigotimes	 Never unscrew except the appointed (marked by an arrow) screws. Do not open the lamp cover while the projector is suspended from a ceiling. This is dangerous, since if the lamp's bulb has broken, the shards will fall out when the cover is opened. In addition, working in high places is dangerous, so ask your local dealer to have the lamp replaced even if the bulb is not broken. Do not use the projector with the lamp cover removed. At the lamp replacing, make sure that the screws are screwed in firmly. Loose screws could result in damage or injury.
0	 Use only the lamp of the specified type. If the lamp breaks soon after the first time it is used, it is possible that there are electrical problems elsewhere besides the lamp. If this happens, contact to your local dealer or a service representative. Handle with care: jolting or scratching could cause the lamp bulb to burst during use. Using the lamp for long periods of time, could cause it dark, not to light up or to burst. When the pictures appear dark, or when the color tone is poor, please replace the lamp as soon as possible. Do not use old (used) lamps; this is a cause of breakage.

Cleaning and replacing the air filter

Please check and clean the air filter periodically. When the indicators or a message prompts you to clean the air filter, comply with it as soon as possible. Replace the air filter when it is damaged or too soiled. To prepare a new air filter, contact to your dealer and tell the air filter type number.

Type number : MU04951

When you replace the lamp, please replace the air filter. An air filter of specified type will come together with a replacement lamp for this projector.

- Turn the projector off, and unplug the power cord.
- Allow the projector to sufficiently cool down.
- Use a vacuum cleaner on and around the filter cover. 2.
- Pull the filter cover knobs while lifting it. The filter unit
- 3. Pull the filter cover knobs while many sites and filter which consists of the filter' cover, air filter and filter frame will come off.
- Use a vacuum cleaner for the filter vent of the 4 projector and the filter frame side of the filter unit. If the air filter is damaged or too soiled, replace it according to the following procedure number 5 to 7. Otherwise, please jump to the procedure number 8.
- 5. Pull the filter frame's know up while and the air filter cover. The filter frame will come off and the air filter Pull the filter frame's knob up while holding the filter will appear.
- Replace the air filter with new one. 6
- Put the filter frame back. 7
- Put the filter unit back into the projector. 8

Filter cover



Filter cover knobs

Filter unit



Filter frame Air filter Filter cover

Cleaning and replacing the air filter (continued)

- $9. \ \ {\rm Turn \ the \ projector \ on \ and \ reset \ the \ filter \ time \ using \ the \ FILTER \ TIME \ item \ in \ the \ EASY \ MENU. }$
 - (1) Press the MENU button to display a menu.
 - (2) Point at the FILTER TIME using the V/▲ button, then press the ► button. A dialog will appear.
 - (3) Press the ▲ button to select RESET on the dialog. It performs resetting the filter time.

▲ WARNING ► Before taking care of the air filter, make sure the power switch is off and the power cable is not plugged in, then allow the projector to cool sufficiently. Taking care of the air filter in a high temperature state of the projector could cause an electric shock, a burn or malfunction to the projector.
 ► Use only the air filter of the specified type. Do not use the projector without the air filter or the filter cover. It could result in a fire or malfunction to the projector.
 ► Clean the air filter periodically. If the air filter becomes clogged by dust or the like, internal temperatures rise and could cause a fire, a burn or malfunction to the projector.

NOTE • Please replace the air filter when it is damaged or too soiled.
When you replace the projection lamp, please replace the air filter. An air filter of specified type will come together with a replacement lamp for this projector.
Please reset the filter time only when you have cleaned or replaced the air filter, for a suitable indication about the air filter.

• The projector may display the message such as "CHECK THE AIR FLOW" or turn off the projector, to prevent the internal heat level rising.

Replacing the internal clock battery

Consumption of the battery makes the internal clock not to work correctly. When the internal clock is wrong or it has stopped, please replace the battery according to the following procedures.

SD card slot cover

Batterv

Battery

Batterv Case

Case

Battery (+)

Battery (-)

Battery Slot

Battery Case

- Turn the projector off, and unplug the power cord. Allow the projector to cool sufficiently.
- After making sure that the projector has cooled adequately,
- 2. After making sure that the projector had been pull the SD card slot cover forward, pushing slightly its edge up, and remove it from the projector.
- Remove the battery case.
- **3.** Hold the battery case gutter by finger nail or other thing and pull out the battery case slowly from the battery slot. While the projector is installed upside down, such as a ceiling mount, please remember the battery will drop down as soon as pulling the battery case out.
- Take the old battery out from the battery case. 4
- Replace a new battery.
- 5. Replace a new pattery. Replace battery with HITACHI MAXELL, Part No.CR2032 only. Use of another battery may present a risk of fire or explosion.

Put a new battery into battery case. Please make sure that the + is facing upward. Insert the battery case slowly into the battery slot until you hear the snap.

- Close the slot cover.
- 6. Replace the SD card slot cover by reversing the procedure used when removing the cover.

▲ WARNING ► Always handle the batteries with care and use them only as directed. Battery may explode if mistreated. Do not recharge, disassemble or dispose of in fire. And also improper use may result in cracking or leakage, which could result in fire, injury and/or pollution of the surrounding environment.

• Be sure to use only the batteries specified.

• Make sure the plus and minus terminals are correctly aligned when loading a battery.

- Keep a battery away from children and pets. If swallowed consult a physician immediately for emergency treatment.
- Do not short circuit or solder a battery.
- Do not allow a battery in a fire or water. Keep batteries in a dark, cool and dry place.
- If you observe battery leakage, wipe out the leakage and then replace a battery.
- If the leakage adheres to your body or clothes, rinse well with water immediately.
- Obey the local laws on disposing the battery.

NOTE • The internal clock's time will be reset when the battery is removed. Please reconfigure the time via the menu or a web browser after replacing the battery. (Date/Time Settings in the User's Manual (detailed) - Network Guide)

Other care

Inside of the projector

In order to ensure the safe use of your projector, please have it cleaned and inspected by your dealer about once every year.

Caring for the lens

If the lens is flawed, soiled or fogged, it could cause deterioration of display quality. Please take care of the lens, being cautious of handling.

- Turn the projector off, and unplug the power cord. Allow the projector to cool sufficiently.
- After making sure that the projector is cool adequately, lightly wipe the lens
- 2. After making sure that the projector to even any with a commercially available lens-cleaning wipe. Do not touch the lens directly with your hand.

Caring for the cabinet and remote control

Incorrect care could have adverse influence such as discoloration, peeling paint, etc.

- Turn the projector off, and unplug the power cord. Allow the projector to cool 1. sufficiently.
- 2. After making sure that the projector is cool adequately, lightly wipe with gauze or a soft cloth.

If the projector is extremely dirty, dip soft cloth in water or a neutral cleaner diluted in water, and wipe lightly after wringing well. Then, wipe lightly with a soft, dry cloth.

AWARNING > Before caring, make sure the power cord is not plugged in. and then allow the projector to cool sufficiently. The care in a high temperature state of the projector could cause a burn and/or malfunction to the projector. ► Never try to care for the inside of the projector personally. Doing is so dangerous.

Avoid wetting the projector or inserting liquids in the projector. It could result in a fire, an electric shock, and/or malfunction to the projector.

• Do not put anything containing water, cleaners or chemicals near the projector. Do not use aerosols or sprays.

▲ CAUTION ▶ Please take right care of the projector according to the following. Incorrect care could cause not only an injury but adverse influence such as discoloration, peeling paint, etc.

> Do not use cleaners or chemicals other than those specified in this manual.

Do not polish or wipe with hard objects.

PureGlare

Troubleshooting

If an abnormal operation should occur, stop using the projector immediately.

▲ WARNING ► Never use the projector if abnormal operations such as smoke, strange odor, excessive sound, damaged casing or elements or cables, penetration of liquids or foreign matter, etc. should occur. In such cases, immediately turn off the power switch and then disconnect the power plug from the power outlet. After making sure that the smoke or odor has stopped, contact to your dealer or service company.

Otherwise if a problem occurs with the projector, the following checks and measures are recommended before requesting repair.

If this does not resolve the problem, please contact your dealer or service company. They will tell you what warranty condition is applied.

Related messages

When some message appears, check and cope with it according to the following table. Although these messages will be automatically disappeared around several minutes, it will be reappeared every time the power is turned on.

Message	Description
NO INPUT IS DETECTED ***	There is no input signal. Please confirm the signal input connection, and the status of the signal source.
SYNC IS OUT OF RANGE *** [fH] **kHz [fV] **Hz	The horizontal or vertical frequency of the input signal is not within the specified range. Please confirm the specs for your projector or the signal source specs.
CHECK THE AIR FLOW	 The internal temperature is rising. Please turn the power off, and allow the projector to cool down at least 20 minutes. After having confirmed the following items, please turn the power ON again. Is there blockage of the air passage aperture? Is the air filter dirty? Does the peripheral temperature exceed 35°C? If the same indication is displayed after the remedy, please set FAN SPEED of the SERVICE item in the OPTION menu to HIGH.
REMINDER *** HRS PASSED AFTER THE LAST FILTER CHECK. FILTER MAINTENANCE IS ESSENTIAL TO REMOVE WARNING MESSAGE, RESET FILTER TIMER. SEE MANUAL FURTHER INFO.	A note of precaution when cleaning the air filter. Please immediately turn the power off, and clean or change the air filter referring to the "Air filter" section of this manual. After you have cleaned or changed the air filter, please be sure to reset the filter timer (166).

Regarding the indicator lamps

When operation of the LAMP, TEMP and POWER indicators differs from usual, check and cope with it according to the following table.

POWER	LAMP	TEMP	Description
indicator	indicator	indicator	
Lighting	Turned	Turned	The projector is in a standby state.
In Orange	off	off	Please refer to the section "Power on/off".
Blinking	Turned	Turned	The projector is warming up.
In <mark>Green</mark>	off	off	Please wait.
Lighting	Turned	Turned	The projector is in an on state.
In Green	off	off	Ordinary operations may be performed.
Blinking	Turned	Turned	The projector is cooling down.
In <mark>Orange</mark>	off	off	Please wait.
Blinking In <mark>Red</mark>	(discre- tionary)	(discre- tionary)	The projector is cooling down. A certain error has been detected. Please wait until POWER indicator finishes blinking, and then perform the proper measure using the item descriptions below.
Blinking In Red or Lighting In <mark>Red</mark>	Lighting In <mark>Red</mark>	Turned off	 The lamp does not light, and there is a possibility that interior portion has become heated. Please turn the power off, and allow the projector to cool down at least 20 minutes. After the projector has sufficiently cooled down, please make confirmation of the following items, and then turn the power on again. Is there blockage of the air passage aperture? Is the air filter dirty? Does the peripheral temperature exceed 35°C? If the same indication is displayed after the remedy, please change the lamp referring to the section "Lamp".
Blinking In Red or Lighting In Red	Blinking In <mark>Red</mark>	Turned off	The lamp cover has not been properly fixed. Please turn the power off, and allow the projector to cool down at least 45 minutes. After the projector has sufficiently cooled down, please make confirmation of the attachment state of the lamp cover. After performing any needed maintenance, turn the power on again. If the same indication is displayed after the remedy, please contact your dealer or service company.
<i>Blinking</i> In Red or Lighting In Red	Turned off	Blinking In <mark>Red</mark>	The cooling fan is not operating. Please turn the power off, and allow the projector to cool down at least 20 minutes. After the projector has sufficiently cooled down, please make confirmation that no foreign matter has become caught in the fan, etc., and then turn the power on again. If the same indication is displayed after the remedy, please contact your dealer or service company.


Regarding the indicator lamps (continued)

POWER	LAMP	TEMP	
indicator		indicator	Description
Blinking In Red or Lighting In Red	Turned off	Lighting In <mark>Red</mark>	There is a possibility that the interior portion has become heated. Please turn the power off, and allow the projector to cool down at least 20 minutes. After the projector has sufficiently cooled down, please make confirmation of the following items, and then turn the power on again. • Is there blockage of the air passage aperture? • Is the air filter dirty? • Does the peripheral temperature exceed 35°C? If the same indication is displayed after the remedy, please set FAN SPEED of SERVICE item in OPTION menu to HIGH (145).
Lighting In <mark>Green</mark>	Simultaneous blinking in Red		It is time to clean the air filter. Please immediately turn the power off, and clean or change the air filter referring to the section "Air Filter". After cleaning or changing the air filter, please be sure to reset the filter timer. After the remedy, reset the power to ON.
Lighting In <mark>Green</mark>	Alternative blinking in <mark>Red</mark>		There is a possibility that the interior portion has become overcooled. Please use the unit within the usage temperature parameters (5° C to 35° C). After the treatment, reset the power to ON.
Blinking in Green for approx. 3 seconds	Turned off	Turned off	At least 1 Power ON schedule is saved to the projector. Please refer to "Schedule Settings" section of User's Manual-Network Guide.

NOTE • When the interior portion has become overheated, for safety purposes, the projector is automatically shut down, and the indicator lamps may also be turned off. In such a case, disconnect the power cord, and wait at least 45 minutes. After the projector has sufficiently cooled down, please make confirmation of the attachment state of the lamp and lamp cover, and then turn the power on again.

Shutting the projector down

Only when the projector can not be turned off by usual procedure ($\square 16$), please push the shutdown switch using a pin or similar, and disconnect the power plug from the power outlet. Before turning it on again, wait at least 10 minutes to make the projector cool down enough.



Resetting all settings

When it is hard to correct some wrong settings, the FACTORY RESET function of SERVICE item in OPTION menu (446) can reset all settings(except LANGUAGE, FILTER TIME, LAMP TIME, FILTER MESSAGE, MIU settings and etc.) to the factory default.

Phenomena that may be easy to be mistaken for machine defects

About the phenomenon confused with a machine defect, check and cope with it according to the following table.

Phenomenon	Cases not involving a machine defect		
Power does not come on.	The electrical power cord is not plugged in. Correctly connect the power cord.	13	
	The main power source has been interrupted during operation such as by a power outage (blackout), etc. Please disconnect the power plug from the power outlet, and allow the projector to cool down at least 10 minutes, then turn the power on again.	13, 16	
	Either there is no lamp and/or lamp cover, or either of these has not been properly fixed. Please turn the power off and disconnect the power plug from the power outlet, and allow the projector to cool down at least 45 minutes. After the projector has sufficiently cooled down, please make confirmation of the attachment state of the lamp and lamp cover, and then turn the power on again.	64, 65	
	The signal cables are not correctly connected. Correctly connect the connection cables.	9	
Neither sounds nor pictures are outputted.	Signal source does not correctly work. Correctly set up the signal source device by referring to the manual of the source device.	-	
	The input changeover settings are mismatched. Select the input signal, and correct the settings.	17, 18	
	The BLANK function for pictures and the MUTE function for sounds are working. AV Mute may be active. Refer to the item "Sound does not come out" and "No pictures are displayed" on the next page to turn off the MUTE and BLANK functions.	17, 22	

Phenomena that may be easy to be mistaken for machine defects (continued)

Phenomenon	Cases not involving a machine defect	Reference page
	The signal cables are not correctly connected. Correctly connect the audio cables.	
	The MUTE function is working. Restore the sound pressing MUTE or VOLUME button on the remote control.	17
	The volume is adjusted to an extremely low level. Adjust the volume to a higher level using the menu function or the remote control.	17
Sound does not	The AUDIO/SPEAKER setting is not correct. Correctly set the AUDIO/SPEAKER in SETUP menu.	36, 37
	The audio on your HDMI equipment is not set to Linear PCM. The HDMI input on this projector supports Linear PCM audio only. Check the audio setting on your HDMI equipment.	11
	The audio on the HDMI input is muted. Change the audio setting in the AUDIO menu.	37
	The digital audio in HDMI signal does not work well. Use the analogue audio, connecting either an RCA audio cable or stereo mini cable.	9
	The lens cover is attached. Remove the lens cover.	4, 16
No pictures are displayed.	The signal cables are not correctly connected. Correctly connect the connection cables.	9
	The brightness is adjusted to an extremely low level. Adjust BRIGHTNESS to a higher level using the menu function.	26, 27
	The computer cannot detect the projector as a plug and play monitor. Make sure that the computer can detect a plug and play monitor using another plug and play monitor.	11
	The BLANK screen is displayed. Press BLANK button on the remote control.	22

Phenomena that may be easy to be mistaken for machine defects (continued)

Phenomenon	Cases not involving a machine defect	Reference page
No pictures or disturbed pictures are displayed on HDMI input	The HDMI cable is not correctly connected. Correctly connect the HDMI cable.	
	Your HDMI equipment is not compatible with the projector This projector can be connected with another equipment that has HDMI or DVI connector, but with some equipment the projector may not work properly.	11
	Your HDMI equipment and the projector are not harmonized. Turn off the both equipment, and turn on them again	-
	The signal format on the HDMI is not supported. Check the video setting on your HDMI equipment.	11
Video screen display freezes.		
Colors have a faded- out appearance, or Color tone is poor.	Color settings are not correctly adjusted. Perform picture adjustments by changing the COLOR TEMP, COLOR, TINT and/or COLOR SPACE settings, using the menu functions.	
	COLOR SPACE setting is not suitable. Change the COLOR SPACE setting to AUTO, RGB, SMPTE240, REC709 or REC601.	32
Pictures appear dark.	The brightness and/or contrast are adjusted to an extremely low level. Adjust BRIGHTNESS and/or CONTRAST settings to a higher level using the menu function.	26, 27
	The WHISPER function is working. Select NORMAL for WHISPER item in the SETUP menu.	26, 36
	The lamp is approaching the end of its product lifetime. Replace the lamp.	64, 65
Pictures appear blurry.	Either the focus and/or horizontal phase settings are not properly adjusted. Adjust the focus using the focus ring, and/or H PHASE using the menu function.	19, 31
	The lens is dirty or misty. Clean the lens referring to the section "Caring for the lens".	68


NOTE • Although bright spots or dark spots may appear on the screen, this is a unique characteristic of liquid crystal displays, and it does not constitute or imply a machine defect.

Specifications

Specifications

Item		Specifications		
Product name		Liquid crystal projector		
Liguid	Panel size	1.6 cm (0.63 type)		
Crystal Panel	Drive system	TFT active matrix		
	Pixels	786,432 pixels (1024 horizontal x 768 vertical)		
Lens		Zoom lens F=1.6 ~ 1.8 f = 18.9~ 22.6 mm (approximately)		
Lamp		220W UHB		
Audio output		7 W		
Power supply		AC 100-120V/3.8A, AC220-240V/1.6A		
Power consumption		350W		
Temperature range		5 ~ 35°C (Operating)		
Size		340 (W) x 117 (H) x 270 (D) mm *Excluding protrusions Please refer to the following figure.		
Weight (mass)		approx. 4.0 kg		
Ports		Computer input port COMPUTER IN1 D-sub 15 pin mini x1 COMPUTER IN2 D-sub 15 pin mini x1 Computer output port MONITOR OUT D-sub 15 pin mini x1 Video input port COMPONENT (Y, Cb/Pb, Cr/Pr) RCA x3 S-VIDEOmini DIN 4 pin x1 VIDEORCA x1	HDMI input port HDMIHDMI connector x1 Audio input/output port AUDIO IN1Stereo mini x1 AUDIO IN2Stereo mini x1 AUDIO IN3RCA x2 AUDIO OUTStereo mini x1 Others USB STORAGEUSB-A x1 SD cardSD card slot x1 USBUSB-B x1 CONTROLD-sub 9 pin x1 LANRJ45 x1	
Optional parts		Lamp: DT00841 Air filter: MU04951 Wireless network card: VA08331 * For more information, contact to your dealer.		

Specifications (continued)



[unit: mm]