

Reset the Lamp Counter on LG 62SX4D

Press and hold enter or OK on TV display and mute on remote at the same time. Hold these down until the lamp reset box appears.